

Алматы (7273)495-231
 Ангарск (3955)60-70-56
 Архангельск (8182)63-90-72
 Астрахань (8512)99-46-04
 Барнаул (3852)73-04-60
 Белгород (4722)40-23-64
 Благовещенск (4162)22-76-07
 Брянск (4832)59-03-52
 Владивосток (423)249-28-31
 Владикавказ (8672)28-90-48
 Владимир (4922)49-43-18
 Волгоград (844)278-03-48
 Вологда (8172)26-41-59
 Воронеж (473)204-51-73
 Екатеринбург (343)384-55-89

Иваново (4932)77-34-06
 Ижевск (3412)26-03-58
 Иркутск (395)279-98-46
 Казань (843)206-01-48
 Калининград (4012)72-03-81
 Калуга (4842)92-23-67
 Кемерово (3842)65-04-62
 Киров (8332)68-02-04
 Коломна (4966)23-41-49
 Кострома (4942)77-07-48
 Краснодар (861)203-40-90
 Красноярск (391)204-63-61
 Курск (4712)77-13-04
 Курган (3522)50-90-47
 Липецк (4742)52-20-81

Магнитогорск (3519)55-03-13
 Москва (495)268-04-70
 Мурманск (8152)59-64-93
 Набережные Челны (8552)20-53-41
 Нижний Новгород (831)429-08-12
 Новокузнецк (3843)20-46-81
 Ноябрьск (3496)41-32-12
 Новосибирск (383)227-86-73
 Омск (3812)21-46-40
 Орел (4862)44-53-42
 Оренбург (3532)37-68-04
 Пенза (8412)22-31-16
 Петрозаводск (8142)55-98-37
 Псков (8112)59-10-37
 Пермь (342)205-81-47

Ростов-на-Дону (863)308-18-15
 Рязань (4912)46-61-64
 Самара (846)206-03-16
 Санкт-Петербург (812)309-46-40
 Саратов (845)249-38-78
 Севастополь (8692)22-31-93
 Саранск (8342)22-96-24
 Симферополь (3652)67-13-56
 Смоленск (4812)29-41-54
 Сочи (862)225-72-31
 Ставрополь (8652)20-65-13
 Сургут (3462)77-98-35
 Сыктывкар (8212)25-95-17
 Тамбов (4752)50-40-97
 Тверь (4822)63-31-35

Тольятти (8482)63-91-07
 Томск (3822)98-41-53
 Тула (4872)33-79-87
 Тюмень (3452)66-21-18
 Ульяновск (8422)24-23-59
 Улан-Удэ (3012)59-97-51
 Уфа (347)229-48-12
 Хабаровск (4212)92-98-04
 Чебоксары (8352)28-53-07
 Челябинск (351)202-03-61
 Череповец (8202)49-02-64
 Чита (3022)38-34-83
 Якутск (4112)23-90-97
 Ярославль (4852)69-52-93

Россия +7(495)268-04-70

Казахстан +7(7172)727-132


Киргизия +996(312)96-26-47

<https://longway.nt-rt.ru/> || yaw@nt-rt.ru



Heavy-Duty Casters





1001-TPR caster with PP core, double ball bearings

							
100 × 50		160	136	115 × 100	85 × 73	20 × 11	1001-100
125 × 50		200	159	115 × 100	85 × 73	20 × 11	1001-125
152 × 50		240	191	115 × 100	85 × 73	20 × 11	1001-152
203 × 50		300	238	115 × 100	85 × 73	20 × 11	1001-203

1002-TPR caster with PP core, double ball bearings

								
100 × 50		160	136	20	115 × 100	85 × 73	20 × 11	1002-100
125 × 50		200	159	30	115 × 100	85 × 73	20 × 11	1002-125
152 × 50		240	191	38	115 × 100	85 × 73	20 × 11	1002-152
203 × 50		300	238	40	115 × 100	85 × 73	20 × 11	1002-203

1003 TPR caster with PP core, double ball bearings

								
100 × 50		160	136	20	115 × 100	85 × 73	20 × 11	1003-100
125 × 50		200	159	30	115 × 100	85 × 73	20 × 11	1003-125
152 × 50		240	191	38	115 × 100	85 × 73	20 × 11	1003-152
203 × 50		300	238	40	115 × 100	85 × 73	20 × 11	1003-203

1004 TPR caster with PP core, roller bearing

							
100X45		140	115X100	85X73	20X11	135	1004-100
127X45		160	115X100	85X73	20X11	159	1004-127
152X45		180	115X100	85X73	20X11	189	1004-152
202X45		220	115X100	85X73	20X11	238	1004-202

1005 TPR caster with PP core, roller bearing

								
100X45		140	115X100	85X73	20X11	136	20	1005-100
127X45		160	115X100	85X73	20X11	159	30	1005-127
152X45		180	115X100	85X73	20X11	191	38	1005-152
202X45		220	115X100	85X73	20X11	238	40	1005-202

1011 PU caster with PP core, double ball bearings

							
100 × 50		200	136	115 × 100	85 × 73	20 × 11	1011-100
125 × 50		280	159	115 × 100	85 × 73	20 × 11	1011-125
152 × 50		320	191	115 × 100	85 × 73	20 × 11	1011-152
203 × 50		400	238	115 × 100	85 × 73	20 × 11	1011-203

1012 PU caster with PP core, double ball bearings

								
100 × 50		200	136	20	115 × 100	85 × 73	20 × 11	1012-100
125 × 50		280	159	30	115 × 100	85 × 73	20 × 11	1012-125
152 × 50		320	191	38	115 × 100	85 × 73	20 × 11	1012-152
203 × 50		400	238	40	115 × 100	85 × 73	20 × 11	1012-203

1013 PU caster with PP core, double ball bearings

								
100 × 50		200	136	20	115 × 100	85 × 73	20 × 11	1013-100
125 × 50		280	159	30	115 × 100	85 × 73	20 × 11	1013-125
152 × 50		320	191	38	115 × 100	85 × 73	20 × 11	1013-152
203 × 50		400	238	40	115 × 100	85 × 73	20 × 11	1013-203


1014 PU caster with PP core, double ball bearings

								
100 × 50		200	135	20	115 × 100	85 × 73	20 × 11	1014-100
125 × 50		280	159	30	115 × 100	85 × 73	20 × 11	1014-125
152 × 50		320	189	36	115 × 100	85 × 73	20 × 11	1014-152
203 × 50		400	238	39.5	115 × 100	85 × 73	20 × 11	1014-203



1020 Nylon wheel with PP core, double ball bearings

					
100 × 50		200	55.5	20	1020-100
125 × 50		280	55.5	20	1020-125
152 × 50		320	55.5	20	1020-152
203 × 50		400	55.5	20	1020-203


1020 Nylon wheel with PP core, double ball bearings

							
100X45		200	135	115X100	85X73	20X11	1021-100
127X45		280	159	115X100	85X73	20X11	1021-125
152X45		320	189	115X100	85X73	20X11	1021-152
202X45		400	238	115X100	85X73	20X11	1021-203



1023 PU caster mold on cast aluminum, double ball bearings

							
125X50		250	159	115X100	85X73	20X11	1023-125
160X50		380	193	115X100	85X73	20X11	1023-160
200X50		550	237	115X100	85X73	20X11	1023-200

1024 PU caster mold on cast aluminum, double ball bearings

								
125X50		250	159	30	115x100	85x73	20x11	1024-125
160X50		380	193	36	115x100	85x73	20x11	1024-160
200X50		550	237	39.5	115x100	85x73	20x11	1024-200

1025 Rubber caster mold on cast aluminium, double ball bearings

							
125X50		250	159	115X100	85X73	20X11	1025-125
152X50		330	189	115X100	85X73	20X11	1025-152
200X50		450	237	115X100	85X73	20X11	1025-200
228X50		480	282	115X100	85X73	20X11	1025-228
250X50		500	294	115X100	85X73	20X11	1025-250

1026 Rubber caster mold on cast aluminium, double ball bearings

								
125X50		250	159	30	115X100	85X73	20X11	1026-125
152X50		330	189	36	115X100	85X73	20X11	1026-152
200X50		450	237	39.5	115X100	85X73	20X11	1026-200
228X50		480	282	49	115X100	85X73	20X11	1026-228
250X50		500	294	49	115X100	85X73	20X11	1026-250

1027 PP caster, roller bearing or plain bearing, Nylon wheel is available.

									
100X50			200	115X100	85X73	20X11	135	1027-100	1027-100-1
125X50			220	115X100	85X73	20X11	159	1027-125	1027-125-1
152X50			250	115X100	85X73	20X11	189	1027-152	1027-152-1
200X50			280	115X100	85X73	20X11	237	1027-200	1027-200-1


1028 PP caster, roller bearing or plain bearing, Nylon wheel is available.

										
100X50			200	115X100	85X73	20X11	135	20	1028-100	1028-100-1
125X50			220	115X100	85X73	20X11	159	30	1028-125	1028-125-1
152X50			250	115X100	85X73	20X11	189	36	1028-152	1028-152-1
200X50			280	115X100	85X73	20X11	237	39.5	1028-200	1028-200-1


1029 PP caster, roller bearing or plain bearing, Nylon wheel is available.

										
100X50			200	115X100	85X73	20X11	135	20	1029-100	1029-100-1
125X50			220	115X100	85X73	20X11	159	30	1029-125	1029-125-1
152X50			250	115X100	85X73	20X11	189	36	1029-152	1029-152-1
200X50			280	115X100	85X73	20X11	237	39.5	1029-200	1029-200-1



1031 PU caster mold on cast iron, double ball bearings

							
100×50		250	135	115×100	85×73	20×11	1031-100
125×50		315	159	115×100	85×73	20×11	1031-125
152×50		400	189	115×100	85×73	20×11	1031-152
200×50		500	237	115×100	85×73	20×11	1031-200




1032 PU caster mold on cast iron, double ball bearings

							
100×50		250	135	20	115X100	85X73	20X11 1032-100
125×50		315	159	30	115X100	85X73	20X11 1032-125
152×50		400	189	36	115X100	85X73	20X11 1032-152
200×50		500	237	39.5	115X100	85X73	20X11 1032-200

1033 PU caster mold on cast iron, double ball bearings

							
100×50		250	135	20	115X100	85X73	20X11 1033-100
125×50		315	159	30	115X100	85X73	20X11 1033-125
152×50		400	189	36	115X100	85X73	20X11 1033-152
200×50		500	237	39.5	115X100	85X73	20X11 1033-200

1034 PU caster mold on cast iron, double ball bearings

							
100×50		250	135	20	115X100	85X73	20X11 1034-100
125×50		315	159	30	115X100	85X73	20X11 1034-125
152×50		400	189	36	115X100	85X73	20X11 1034-152
200×50		500	237	39.5	115X100	85X73	20X11 1034-200

1041 PU caster mold on cast iron, roller bearing

							
100×50		230	135	115X100	85X73	20X11	1041-100
125×50		380	159	115X100	85X73	20X11	1041-125
152×50		400	189	115X100	85X73	20X11	1041-152
200×50		500	237	115X100	85X73	20X11	1041-200
250×50		575	294	115X100	85X73	20X11	1041-250

1041A PU caster mold on cast iron, roller bearing

1042 PU caster mold on cast iron, roller bearing

							
100×50		230	135	115X100	85X73	20X11	1042-100
125×50		280	159	115X100	85X73	20X11	1042-125
152×50		400	189	115X100	85X73	20X11	1042-152
200×50		500	237	115X100	85X73	20X11	1042-200

1043 PU caster mold on cast iron, roller bearing

								
100×50		230	135	20	115X100	85X73	20X11	1043-100
125×50		280	159	30	115X100	85X73	20X11	1043-125
152×50		400	189	36	115X100	85X73	20X11	1043-152
200×50		500	237	39.5	115X100	85X73	20X11	1043-200
250×50		575	294	49	115X100	85X73	20X11	1043-250

1043A PU caster mold on cast iron, roller bearing

								
100X50		230	115X100	85X73	20X11	135	20	1043A-100
125X50		280	115X100	85X73	20X11	159	30	1043A-125
152X50		400	115X100	85X73	20X11	189	36	1043A-152
200X50		500	115X100	85X73	20X11	237	39.5	1043A-200

1044 PU caster mold on cast iron, roller bearing

								
100 × 50		230	135	20	115X100	85X73	20X11	1044-100
125 × 50		280	159	30	115X100	85X73	20X11	1044-125
152 × 50		400	189	36	115X100	85X73	20X11	1044-152
200 × 50		500	237	39.5	115X100	85X73	20X11	1044-200

1045 PU caster mold on cast iron, roller bearing

								
100×50		230	135	20	115X100	85X73	20X11	1045-100
125×50		280	159	30	115X100	85X73	20X11	1045-125
152×50		400	189	36	115X100	85X73	20X11	1045-152
200×50		500	237	39.5	115X100	85X73	20X11	1045-200
250×50		575	294	49	115X100	85X73	20X11	1045-250

1046 PU caster mold on cast iron, roller bearing

								
100×50		230	135	20	115X100	85X73	20X11	1046-100
125×50		280	159	30	115X100	85X73	20X11	1046-125
152×50		400	189	36	115X100	85X73	20X11	1046-152
200×50		500	237	39.5	115X100	85X73	20X11	1046-200

1047A PU caster mold on cast iron, roller bearing

								
100X50		230	115X100	85X73	20X11	135	20	1047A-100
125X50		280	115X100	85X73	20X11	159	30	1047A-125
152X50		400	115X100	85X73	20X11	189	36	1047A-152
200X50		500	115X100	85X73	20X11	237	39.5	1047A-200

1051 PU caster with PP core, roller bearing or plain bearing

								 (Roller bearing)	 (Plain bearing)
100X50			200	115X100	85X73	20X11	136	1051-100	1051-100-1
125X50			250	115X100	85X73	20X11	159	1051-125	1051-125-1
152X50			300	115X100	85X73	20X11	191	1051-152	1051-152-1
200X50			370	115X100	85X73	20X11	238	1051-203	1051-203-1

1052 PU caster with PP core, roller bearing or plain bearing

								 (Roller bearing)	 (Plain bearing)
100X50			200	115X100	85X73	20X11	136	20	1052-100 1052-100-1
125X50			220	115X100	85X73	20X11	159	30	1052-125 1052-125-1
152X50			250	115X100	85X73	20X11	191	38	1052-152 1052-152-1
203X50			270	115X100	85X73	20X11	238	39.5	1052-203 1052-203-1

1053 PU caster with PP core, roller bearing or plain bearing

								 (Roller bearing)	 (Plain bearing)
100X50			200	115X100	85X73	20X11	136	1053-100	1053-100-1
125X50			250	115X100	85X73	20X11	159	1053-125	1053-125-1
152X50			300	115X100	85X73	20X11	191	1053-152	1053-152-1
203X50			370	115X100	85X73	20X11	238	1053-203	1053-203-1

1054 PU caster with PP core, roller bearing or plain bearing

										
100X50			200	115X100	85X73	20X11	136	20	1054-100	1054-100-1
125X50			250	115X100	85X73	20X11	159	30	1054-125	1054-125-1
152X50			300	115X100	85X73	20X11	191	38	1054-152	1054-152-1
203X50			370	115X100	85X73	20X11	238	40	1054-203	1054-203-1

1061 Phenolic caster, roller bearing

							
100×50		250	136	115×100	85×73	20×11	1061-100
125×50		300	159	115×100	85×73	20×11	1061-125
150×50		400	190	115×100	85×73	20×11	1061-150
200×50		450	237	115×100	85×73	20×11	1061-200

1062 Phenolic caster, roller bearing

								
100×50		250	136	20	115X100	85X73	20X11	1062-100
125×50		300	159	30	115X100	85X73	20X11	1062-125
150×50		400	190	38	115X100	85X73	20X11	1062-150
203×50		450	237	40	115X100	85X73	20X11	1062-203

1063 Phenolic caster, roller bearing

							
100×50		250	136	115×100	85×73	20×11	1063-100
125×50		300	159	115×100	85×73	20×11	1063-125
150×50		400	190	115×100	85×73	20×11	1063-150
200×50		450	237	115×100	85×73	20×11	1063-200

1064 Phenolic caster, roller bearing

								
100×50		250	136	20	115X100	85X73	20X11	1064-100
125×50		300	159	30	115X100	85X73	20X11	1064-125
150×50		400	190	38	115X100	85X73	20X11	1064-150
200×50		450	237	40	115X100	85X73	20X11	1064-200

1071 PP caster with PP core, roller bearing or plain bearing

								 (Roller bearing)	 (Plain bearing)
100X50			150	115X100	85X73	20X11	136	1071-100	1071-100-1
125X50			200	115X100	85X73	20X11	159	1071-125	1071-125-1
152X50			250	115X100	85X73	20X11	191	1071-152	1071-152-1
203X50			300	115X100	85X73	20X11	238	1071-203	1071-203-1

1072 PP caster with PP core, roller bearing or plain bearing

									 (Roller bearing)	 (Plain bearing)
100X50			150	115X100	85X73	20X11	136	20	1072-100	1072-100-1
125X50			200	115X100	85X73	20X11	159	30	1072-125	1072-125-1
152X50			250	115X100	85X73	20X11	191	38	1072-152	1072-152-1
203X50			300	115X100	85X73	20X11	238	40	1072-203	1072-203-1

1081 Caster with rubber mold on cast iron wheel, roller bearing or plain bearing

									 (Roller bearing)	 (Double ball bearings)
100×50		130			115X100	85X73	20X11	136	1081-100	1081-136-1
125×50		160			115X100	85X73	20X11	159	1081-125	1081-159-1
150×50		230		250	115X100	85X73	20X11	190	1081-150	1081-190-1
200×50		280		300	115X100	85X73	20X11	237	1081-200	1081-237-1
250×50		350		350	115X100	85X73	20X11	293	1081-250	1081-293-1

1082 Caster with rubber mold on cast iron wheel, roller bearing or plain bearing

											
100×50		130			115X100	85X73	20X11	136	1082-100	1082-136-1	
125×50		160			115X100	85X73	20X11	159	1082-125	1082-159-1	
150×50		230		250	115X100	85X73	20X11	190	1082-150	1082-190-1	
200×50		280		300	115X100	85X73	20X11	237	1082-200	1082-237-1	

1083 Caster with rubber mold on cast iron wheel, roller bearing or plain bearing

											
100×50		130			115X100	85X73	20X11	136	20	1083-100	
125×50		160			115X100	85X73	20X11	159	30	1083-125	
150×50		230		250	115X100	85X73	20X11	190	38	1083-150	1083-150-1
200×50		280		300	115X100	85X73	20X11	237	40	1083-200	1083-200-1
250×50		350		350	115X100	85X73	20X11	293	49	1083-250	1083-250-1

1084 Caster with rubber mold on cast iron wheel, roller bearing or plain bearing

											
100×50		130			115X100	85X73	20X11	136	20	1084-100	
125×50		160			115X100	85X73	20X11	159	30	1084-125	
150×50		230		250	115X100	85X73	20X11	190	38	1084-150	1084-150-1
200×50		280		300	115X100	85X73	20X11	237	40	1084-200	1084-200-1

1085 Caster with rubber mold on cast iron wheel, roller bearing or plain bearing

											
100×50		130			115X100	85X73	20X11	136	20	1085-100	
125×50		160			115X100	85X73	20X11	159	30	1085-125	
150×50		230		250	115X100	85X73	20X11	190	38	1085-150	1085-150-1
200×50		280		300	115X100	85X73	20X11	237	40	1085-200	1085-200-1

1086 Caster with rubber mold on cast iron wheel, roller bearing or plain bearing

												
100×50		130			115X100	85X73	20X11	136	20	1086-100		
125×50		160			115X100	85X73	20X11	159	30	1086-125		
150×50		230		250	115X100	85X73	20X11	190	38	1086-150	1086-150-1	
200×50		280		300	115X100	85X73	20X11	237	40	1086-200	1086-200-1	
250×50		350		350	115X100	85X73	20X11	293	49	1086-250	1086-250-1	

1091 TPR caster with PP core, plain bearing

							
100×50		140	136	115X100	85X73	20X11	1091-100
125×50		160	159	115X100	85X73	20X11	1091-125
152×50		180	191	115X100	85X73	20X11	1091-152
203×50		220	238	115X100	85X73	20X11	1091-203

1092 TPR caster with PP core, plain bearing

								
100×50		140	136	20	115X100	85X73	20X11	1092-100
125×50		160	159	30	115X100	85X73	20X11	1092-125
152×50		180	191	38	115X100	85X73	20X11	1092-152
203×50		220	238	40	115X100	85X73	20X11	1092-203

1101 Rubber caster with steel core, double ball bearings

							
160×50		150	194	115×100	85×73	20×11	1101-160
206×58		235	239	115×100	85×73	20×11	1101-206

1102 Rubber caster with steel core, double ball bearings

								
160×50		150	194	38	115X100	85X73	20X11	1102-160
206×58		235	239	40	115X100	85X73	20X11	1102-206

1111 PP caster, double ball bearings

							
100×44		150	136	115X100	85X73	20X11	1111-100
122×44		210	158	115X100	85X73	20X11	1111-122
150×44		290	190	115X100	85X73	20X11	1111-150
200×44		350	237	115X100	85X73	20X11	1111-200

1112 PP caster, double ball bearings

								
100×44		150	136	20	115X100	85X73	20X11	1112-100
122×44		210	158	30	115X100	85X73	20X11	1112-122
150×44		290	190	38	115X100	85X73	20X11	1112-150
200×44		350	237	40	115X100	85X73	20X11	1112-200

1121 Pneumatic rubber caster with steel core

							
215×60		100	254	115X100	85X73	20X11	1121-215
266×90		130	303	115X100	85X73	20X11	1121-266

1122 Pneumatic rubber caster with steel core

								
215×60		100	254	51.5	115X100	85X73	20X11	1122-215
266×90		130	303	51.5	115X100	85X73	20X11	1122-266

1131 Cast iron caster, roller bearing

							
100×50		300	137	115X100	85X73	20X11	1131-100
127×50		350	160	115X100	85X73	20X11	1131-127
152×50		400	191	115X100	85X73	20X11	1131-152
203×50		500	238	115X100	85X73	20X11	1131-203

1132 Cast iron caster, roller bearing

								
100×50		300	137	20	115X100	85X73	20X11	1132-100
127×50		350	160	30	115X100	85X73	20X11	1132-127
152×50		400	191	38	115X100	85X73	20X11	1132-152
203×50		500	238	40	115X100	85X73	20X11	1132-203

1137 Elastic rubber caster with nylon core, double ball bearing

							
125×50		180	159	115X100	85X73	20X11	1137-125
160×50		270	191	115X100	85X73	20X11	1137-152
200×50		350	237	115X100	85X73	20X11	1137-200

1138 Elastic rubber caster with nylon core, double ball bearing

								
125×50		180	159	30	115X100	85X73	20X11	1138-125
160×50		270	191	38	115X100	85X73	20X11	1138-152
200×50		350	237	40	115X100	85X73	20X11	1138-200

1141 Cast iron caster, roller bearing

							
101×50		300	137	115X100	85X73	20X11	1141-101
127×50		350	160	115X100	85X73	20X11	1141-127
152×50		400	191	115X100	85X73	20X11	1141-152
203×50		500	238	115X100	85X73	20X11	1141-203

1142 Cast iron caster, roller bearing

								
101×50		300	137	20	115X100	85X73	20X11	1142-101
127×50		350	160	30	115X100	85X73	20X11	1142-127
152×50		400	191	38	115X100	85X73	20X11	1142-152
203×50		500	238	40	115X100	85X73	20X11	1142-203

1143 Nylon caster, roller bearing

								
152 × 40		350	191		115X100	85X73	20X11	1143-152
200 × 48		400	237		115X100	85X73	20X11	1143-200

1144 Nylon caster, roller bearing

								
152 × 40		350	191	38	115X100	85X73	20X11	1144-152
200 × 48		400	237	40	115X100	85X73	20X11	1144-200

Алматы (7273)495-231
 Ангaрск (3955)60-70-56
 Архангельск (8182)63-90-72
 Астрахань (8512)99-46-04
 Барнаул (3852)73-04-60
 Белгород (4722)40-23-64
 Благовещенск (4162)22-76-07
 Брянск (4832)59-03-52
 Владивосток (423)249-28-31
 Владикавказ (8672)28-90-48
 Владимир (4922)49-43-18
 Волгоград (844)278-03-48
 Вологда (8172)26-41-59
 Воронеж (473)204-51-73
 Екатеринбург (343)384-55-89

Иваново (4932)77-34-06
 Ижевск (3412)26-03-58
 Иркутск (395)279-98-46
 Казань (843)206-01-48
 Калининград (4012)72-03-81
 Калуга (4842)92-23-67
 Кемерово (3842)65-04-62
 Киров (8332)68-02-04
 Коломна (4966)23-41-49
 Кострома (4942)77-07-48
 Краснодар (861)203-40-90
 Красноярск (391)204-63-61
 Курск (4712)77-13-04
 Курган (3522)50-90-47
 Липецк (4742)52-20-81

Магнитогорск (3519)55-03-13
 Москва (495)268-04-70
 Мурманск (8152)59-64-93
 Набережные Челны (8552)20-53-41
 Нижний Новгород (831)429-08-12
 Новокузнецк (3843)20-46-81
 Ноябрьск (3496)41-32-12
 Новосибирск (383)227-86-73
 Омск (3812)21-46-40
 Орел (4862)44-53-42
 Оренбург (3532)37-68-04
 Пенза (8412)22-31-16
 Петрозаводск (8142)55-98-37
 Псков (8112)59-10-37
 Пермь (342)205-81-47

Ростов-на-Дону (863)308-18-15
 Рязань (4912)46-61-64
 Самара (846)206-03-16
 Санкт-Петербург (812)309-46-40
 Саратов (845)249-38-78
 Севастополь (8692)22-31-93
 Саранск (8342)22-96-24
 Симферополь (3652)67-13-56
 Смоленск (4812)29-41-54
 Сочи (862)225-72-31
 Ставрополь (8652)20-65-13
 Сургут (3462)77-98-35
 Сыктывкар (8212)25-95-17
 Тамбов (4752)50-40-97
 Тверь (4822)63-31-35

Тольятти (8482)63-91-07
 Томск (3822)98-41-53
 Тула (4872)33-79-87
 Тюмень (3452)66-21-18
 Ульяновск (8422)24-23-59
 Улан-Удэ (3012)59-97-51
 Уфа (347)229-48-12
 Хабаровск (4212)92-98-04
 Чебоксары (8352)28-53-07
 Челябинск (351)202-03-61
 Череповец (8202)49-02-64
 Чита (3022)38-34-83
 Якутск (4112)23-90-97
 Ярославль (4852)69-52-93

Россия +7(495)268-04-70

Казахстан +7(7172)727-132

Киргизия +996(312)96-26-47

<https://longway.nt-rt.ru/> || yaw@nt-rt.ru