

Алматы (7273)495-231
 Ангарск (3955)60-70-56
 Архангельск (8182)63-90-72
 Астрахань (8512)99-46-04
 Барнаул (3852)73-04-60
 Белгород (4722)40-23-64
 Благовещенск (4162)22-76-07
 Брянск (4832)59-03-52
 Владивосток (423)249-28-31
 Владикавказ (8672)28-90-48
 Владимир (4922)49-43-18
 Волгоград (844)278-03-48
 Вологда (8172)26-41-59
 Воронеж (473)204-51-73
 Екатеринбург (343)384-55-89

Иваново (4932)77-34-06
 Ижевск (3412)26-03-58
 Иркутск (395)279-98-46
 Казань (843)206-01-48
 Калининград (4012)72-03-81
 Калуга (4842)92-23-67
 Кемерово (3842)65-04-62
 Киров (8332)68-02-04
 Коломна (4966)23-41-49
 Кострома (4942)77-07-48
 Краснодар (861)203-40-90
 Красноярск (391)204-63-61
 Курск (4712)77-13-04
 Курган (3522)50-90-47
 Липецк (4742)52-20-81

Магнитогорск (3519)55-03-13
 Москва (495)268-04-70
 Мурманск (8152)59-64-93
 Набережные Челны (8552)20-53-41
 Нижний Новгород (831)429-08-12
 Новокузнецк (3843)20-46-81
 Ноябрьск (3496)41-32-12
 Новосибирск (383)227-86-73
 Омск (3812)21-46-40
 Орел (4862)44-53-42
 Оренбург (3532)37-68-04
 Пенза (8412)22-31-16
 Петрозаводск (8142)55-98-37
 Псков (8112)59-10-37
 Пермь (342)205-81-47

Ростов-на-Дону (863)308-18-15
 Рязань (4912)46-61-64
 Самара (846)206-03-16
 Санкт-Петербург (812)309-46-40
 Саратов (845)249-38-78
 Севастополь (8692)22-31-93
 Саранск (8342)22-96-24
 Симферополь (3652)67-13-56
 Смоленск (4812)29-41-54
 Сочи (862)225-72-31
 Ставрополь (8652)20-65-13
 Сургут (3462)77-98-35
 Сыктывкар (8212)25-95-17
 Тамбов (4752)50-40-97
 Тверь (4822)63-31-35

Тольятти (8482)63-91-07
 Томск (3822)98-41-53
 Тула (4872)33-79-87
 Тюмень (3452)66-21-18
 Ульяновск (8422)24-23-59
 Улан-Удэ (3012)59-97-51
 Уфа (347)229-48-12
 Хабаровск (4212)92-98-04
 Чебоксары (8352)28-53-07
 Челябинск (351)202-03-61
 Череповец (8202)49-02-64
 Чита (3022)38-34-83
 Якутск (4112)23-90-97
 Ярославль (4852)69-52-93

Россия +7(495)268-04-70

Казахстан +7(7172)727-132

Киргизия +996(312)96-26-47

<https://longway.nt-rt.ru/> || yaw@nt-rt.ru

Light-Duty, Furniture Casters



2001 TPR caster with PP core, ball bearing, zinc plated or chrome plated

									
80 × 32		100	92 × 64	75 × 45	8.5	114	27	2001-80	
100 × 32		130	92 × 64	75 × 45	8.5	138	34	2001-100	
125 × 32		150	92 × 64	75 × 45	8.5	161	34	2001-125	

2002 TPR caster with PP core, ball bearing, zinc plated or chrome plated

									
80 × 32		100	92 × 64	75 × 45	8.5	114	30	90	2002-80
100 × 32		130	92 × 64	75 × 45	8.5	138	34	90	2002-100
125 × 32		150	92 × 64	75 × 45	8.5	161	28	90	2002-125

2003 TPR caster with PP core, ball bearing, zinc plated or chrome plated

						
80 × 32		100	12.5	111	27	2003-80
100 × 32		130	12.5	135	34	2003-100
125 × 32		150	12.5	158	34	2003-125

2004 TPR caster with PP core, ball bearing, zinc plated or chrome plated

							
80 × 32		100	12.5	111	30	90	2004-80
100 × 32		130	12.5	135	34	90	2004-100
125 × 32		150	12.5	158	28	90	2004-125


2005 TPR caster with PP core, ball bearing, zinc plated or chrome plated

						
80 × 32		100	111	27	5/8 × 25	2005-80
100 × 32		130	135	34	5/8 × 25	2005-100
125 × 32		150	158	34	5/8 × 25	2005-125

2006 TPR caster with PP core, ball bearing, zinc plated or chrome plated

							
80 × 32		100	111	30	5/8 × 25	90	2006-80
100 × 32		130	135	34	5/8 × 25	90	2006-100
125 × 32		150	158	28	5/8 × 25	90	2006-125

2010 PP caster, plain bearing

								
38×23		60.5×44	49×23	6.3	49	15	50	2010-38
50×25		66.5×48.5	54×24.5	6.3	65	16	60	2010-50
63×28		98×70	76×44	8.5	82	28	80	2010-63
75×30		105×80	87×60	8.5	97	26	100	2010-75
100×31		127.5×101	103×76	10.5	127	38	140	2010-100

2010B PP caster, plain bearing

								
50×25		60	66.5×48.5	54×24.5	6.3	65	16	2010B-50
63×28		80	98×70	76×44	8.5	82	28	2010B-63
75×30		100	105×80	87×60	8.5	97	26	2010B-75

2011 PP caster, plain bearing

							
38×23		50	61×38	49×23	6.3	49	2011-38
50×25		60	66×42	54×24	6.3	65	2011-50
63×28		80	98×55	82×25	8.5	82	2011-63
75×30		100	103×61	84.5×36	8.5	97	2011-75
100×31		140	130×69	110×38	10.5	127	2011-100

2012 Hard rubber caster, plain bearing

								
38×23		40	60.5×44	49×23	6.3	49	15	2012-38
50×23		60	66.5×48.5	54×24.5	6.3	65	16	2012-50
63×28		80	98×70	76×44	8.5	82	28	2012-63
75×30		100	105×80	87×60	8.5	97	26	2012-75

2012B Hard rubber caster, plain bearing

								
50×25		60	66.5×48.5	54×24	6.3	65	16	2012B-50
63×28		80	98×70	76×44	8.5	82	28	2012B-63
75×30		100	105×80	87×60	8.5	97	26	2012B-75

2013 Hard rubber caster, plain bearing

							
38×23		40	61×38	49×23	6.3	49	2013-38
50×25		60	66×42	54×24	6.3	65	2013-50
63×28		80	98×55	82×25	8.5	82	2013-63
75×30		100	103×61	84.5×36	8.5	97	2013-75

2021 PVC caster with PP core, plain bearing

								
75×20		70	92	23.5	11×35		2021-75	2021-75-1
100×22		90	118	36	11×35		2021-100	2021-100-1
127×26		105	147	31	11×35		2021-127	2021-127-1

2022 PVC caster with PP core, plain bearing

							
75×20		70	92	23.5	11 × 35	2022-75	2022-75-1
100×22		90	118	36	11 × 35	2022-100	2022-100-1
127×26		105	147	31	11 × 35	2022-127	2022-127-1

2026 Hard rubber caster, plain bearing or roller bearing

										
100 × 38			130	105×80	67×52	19.5×9.6	128	37	2026-100	2026-100-1

2027 Hard rubber caster, plain bearing or roller bearing

										
100 × 38			130	105×80	67×52	19.5×9.6	128	37	2027-100	2027-100-1

2028 Rubber caster, plain bearing

								
50 × 22		30	58 × 48	46 × 35	6.3	65	21	2028-50
65 × 23		40	65 × 54	51.5 × 38.5	7.3	82	24	2028-65
75 × 28		60	70 × 59	53 × 40	8.5	94	26	2028-75

2029 Rubber caster, plain bearing

							
50×22		30	58×40	43.5×23.5	6.3	65	2029-50
65×23		40	71×47	55×26	8	82	2029-65
75×28		60	70×61	53×40	8.5×11	94	2029-75


2030 Rubber caster, plain bearing

								
50×22		30	58×48	46×35	6.3	65	21	2030-50
65×23		40	65×54	51.5×38.5	7.3	82	24	2030-65
75×28		60	70×59	53×40	8.5	94	26	2030-75

2035 Rubber caster, plain bearing

						
50×22		30	63.5	21	M10×15	2035-50
65×23		40	80.5	24	M10×15	2035-65
75×28		60	92.5	26	M10×30	2035-75


2037 PP caster, plain bearing

								
50×23		40	58×48	46×35	6.3	65	21	2037-50
63×24		50	65×54	51.5×38.5	7.3	81	24	2037-63
75×30		65	70×59	53×40	8.5	94	26	2037-75

2038 PP caster, plain bearing

							
50 × 23		40	58 × 40	43.5 × 23.5	6	65	2038-50
63 × 24		50	71 × 47	54 × 26	8	81	2038-63
75 × 30		65	70 × 61	53 × 40	8.5 × 11	94	2038-75

2039 PP caster, plain bearing

								
50 × 23		40	58 × 48	46 × 35	6.3	65	21	2039-50
63 × 24		50	65 × 54	51.5 × 38.5	7.3	81	24	2039-63
75 × 30		65	70 × 59	53 × 40	8.5	94	26	2039-75

2042 PP caster, plain bearing

								
50 × 23		50	58 × 48	46 × 35	6.3	65	21	2042-50
63 × 24		60	65 × 54	51.5 × 38.5	7.3	81	24	2042-63
75 × 30		100	70 × 59	53 × 40	8.5	94	26	2042-75

2043 PP caster, plain bearing

							
50 × 23		50	58 × 40	43.5 × 23.5	6.3	65	2043-50
63 × 24		60	71 × 47	55 × 26	8.0	81	2043-63
75 × 30		100	70 × 61	53 × 40	8.5 × 11	94	2043-75

2044 PP caster, plain bearing

						
50 × 23		45	63.5	21	M10 × 15	2044-50
63 × 24		55	79.5	24	M10 × 15	2044-63

F-A03 TPR caster with PP core, double ball bearings, zinc plated or chrome plated

								
80X24		70	92X64	75X45	8.5	114	27	F-A03-80
100X32		100	92X64	75X45	8.5	138	34	F-A03-100
125X32		120	92X64	75X45	8.5	161	34	F-A03-125
152X32		150	106X80	80X60	19.8X9.8	193	45	F-A03-152

F-A04 TPR caster with PP core, double ball bearings, zinc plated or chrome plated

									
80X24		70	92X64	75X45	8.5	114	30	90	F-A04-80
100X32		100	92X64	75X45	8.5	138	34	90	F-A04-100
125X32		120	92X64	75X45	8.5	161	28	90	F-A04-125
152X32		150	106X80	80X60	19.8X9.8	193	50	115	F-A04-152

F-A05 TPR caster with PP core, double ball bearings, zinc plated or chrome plated

						
80X24		70	27	111	12.5	F-A05-80
100X32		100	34	135	12.5	F-A05-100
125X32		120	34	158	12.5	F-A05-125
152X32		150	45	190	12.5	F-A05-152

F-A06 TPR caster with PP core, double ball bearings, zinc plated or chrome plated

							
80X24		70	30	111	12.5	90	F-A06-80
100X32		100	34	135	12.5	90	F-A06-100
125X32		120	28	158	12.5	90	F-A06-125
152X32		150	50	190	12.5	115	F-A06-152

F-A07 TPR caster with PP core, double ball bearings, zinc plated or chrome plated

							
80X24		70	111	27	5/8	25	F-A07-80
100X32		100	135	34	5/8	25	F-A07-100
125X32		120	158	34	5/8	25	F-A07-125
152X32		150	190	45	5/8	25	F-A07-152

F-A08 TPR caster with PP core, double ball bearings, zinc plated or chrome plated

								
80X24		70	111	30	5/8	25	90	F-A08-80
100X32		100	135	34	5/8	25	90	F-A08-100
125X32		120	158	28	5/8	25	90	F-A08-125
152X32		150	190	50	5/8	25	115	F-A08-152

2104 PP bed caster, plain bearing

					
50×56		80	61	9.5×41	2104-50


2109 TPR ball caster with PP core, plain bearing

								
40		40	38×38	27×27	5.2	52	16	2109-40
50		60	38×38	27×27	5.2	60	25	2109-50

2110 TPR ball caster with PP core, plain bearing

						
40		40	M10×15	52	16	2110-40
50		60	M10×15	60	25	2110-50

2111 TPR ball caster with PP core, plain bearing

						
40		40	11×38	52	16	2111-40
50		60	11×38	60	25	2111-50

2112 TPR ball caster with PP core, plain bearing

40		40	9.2×38	52	16	2112-40
50		60	9.2×38	60	25	2112-50

Алматы (7273)495-231
Ангарск (3955)60-70-56
Архангельск (8182)63-90-72
Астрахань (8512)99-46-04
Барнаул (3852)73-04-60
Белгород (4722)40-23-64
Благовещенск (4162)22-76-07
Брянск (4832)59-03-52
Владивосток (423)249-28-31
Владикавказ (8672)28-90-48
Владимир (4922)49-43-18
Волгоград (844)278-03-48
Вологда (8172)26-41-59
Воронеж (473)204-51-73
Екатеринбург (343)384-55-89

Иваново (4932)77-34-06
Ижевск (3412)26-03-58
Иркутск (395)279-98-46
Казань (843)206-01-48
Калининград (4012)72-03-81
Калуга (4842)92-23-67
Кемерово (3842)65-04-62
Киров (8332)68-02-04
Коломна (4966)23-41-49
Кострома (4942)77-07-48
Краснодар (861)203-40-90
Красноярск (391)204-63-61
Курск (4712)77-13-04
Курган (3522)50-90-47
Липецк (4742)52-20-81

Магнитогорск (3519)55-03-13
Москва (495)268-04-70
Мурманск (8152)59-64-93
Набережные Челны (8552)20-53-41
Нижний Новгород (831)429-08-12
Новокузнецк (3843)20-46-81
Ноябрьск (3496)41-32-12
Новосибирск (383)227-86-73
Омск (3812)21-46-40
Орел (4862)44-53-42
Оренбург (3532)37-68-04
Пенза (8412)22-31-16
Петрозаводск (8142)55-98-37
Псков (8112)59-10-37
Пермь (342)205-81-47

Ростов-на-Дону (863)308-18-15
Рязань (4912)46-61-64
Самара (846)206-03-16
Санкт-Петербург (812)309-46-40
Саратов (845)249-38-78
Севастополь (8692)22-31-93
Саранск (8342)22-96-24
Симферополь (3652)67-13-56
Смоленск (4812)29-41-54
Сочи (862)225-72-31
Ставрополь (8652)20-65-13
Сургут (3462)77-98-35
Сыктывкар (8212)25-95-17
Тамбов (4752)50-40-97
Тверь (4822)63-31-35

Тольятти (8482)63-91-07
Томск (3822)98-41-53
Тула (4872)33-79-87
Тюмень (3452)66-21-18
Ульяновск (8422)24-23-59
Улан-Удэ (3012)59-97-51
Уфа (347)229-48-12
Хабаровск (4212)92-98-04
Чебоксары (8352)28-53-07
Челябинск (351)202-03-61
Череповец (8202)49-02-64
Чита (3022)38-34-83
Якутск (4112)23-90-97
Ярославль (4852)69-52-93

Россия +7(495)268-04-70

Казахстан +7(7172)727-132

Киргизия +996(312)96-26-47

<https://longway.nt-rt.ru/> || yaw@nt-rt.ru