

Алматы (7273)495-231
 Ангарск (3955)60-70-56
 Архангельск (8182)63-90-72
 Астрахань (8512)99-46-04
 Барнаул (3852)73-04-60
 Белгород (4722)40-23-64
 Благовещенск (4162)22-76-07
 Брянск (4832)59-03-52
 Владивосток (423)249-28-31
 Владикавказ (8672)28-90-48
 Владимир (4922)49-43-18
 Волгоград (844)278-03-48
 Вологда (8172)26-41-59
 Воронеж (473)204-51-73
 Екатеринбург (343)384-55-89

Иваново (4932)77-34-06
 Ижевск (3412)26-03-58
 Иркутск (395)279-98-46
 Казань (843)206-01-48
 Калининград (4012)72-03-81
 Калуга (4842)92-23-67
 Кемерово (3842)65-04-62
 Киров (8332)68-02-04
 Коломна (4966)23-41-49
 Кострома (4942)77-07-48
 Краснодар (861)203-40-90
 Красноярск (391)204-63-61
 Курск (4712)77-13-04
 Курган (3522)50-90-47
 Липецк (4742)52-20-81

Магнитогорск (3519)55-03-13
 Москва (495)268-04-70
 Мурманск (8152)59-64-93
 Набережные Челны (8552)20-53-41
 Нижний Новгород (831)429-08-12
 Новокузнецк (3843)20-46-81
 Ноябрьск (3496)41-32-12
 Новосибирск (383)227-86-73
 Омск (3812)21-46-40
 Орел (4862)44-53-42
 Оренбург (3532)37-68-04
 Пенза (8412)22-31-16
 Петрозаводск (8142)55-98-37
 Псков (8112)59-10-37
 Пермь (342)205-81-47

Ростов-на-Дону (863)308-18-15
 Рязань (4912)46-61-64
 Самара (846)206-03-16
 Санкт-Петербург (812)309-46-40
 Саратов (845)249-38-78
 Севастополь (8692)22-31-93
 Саранск (8342)22-96-24
 Симферополь (3652)67-13-56
 Смоленск (4812)29-41-54
 Сочи (862)225-72-31
 Ставрополь (8652)20-65-13
 Сургут (3462)77-98-35
 Сыктывкар (8212)25-95-17
 Тамбов (4752)50-40-97
 Тверь (4822)63-31-35

Тольятти (8482)63-91-07
 Томск (3822)98-41-53
 Тула (4872)33-79-87
 Тюмень (3452)66-21-18
 Ульяновск (8422)24-23-59
 Улан-Удэ (3012)59-97-51
 Уфа (347)229-48-12
 Хабаровск (4212)92-98-04
 Чебоксары (8352)28-53-07
 Челябинск (351)202-03-61
 Череповец (8202)49-02-64
 Чита (3022)38-34-83
 Якутск (4112)23-90-97
 Ярославль (4852)69-52-93

Россия +7(495)268-04-70

Казахстан +7(7172)727-132









Киргизия +996(312)96-26-47

<https://longway.nt-rt.ru/> || yaw@nt-rt.ru

Industrial Rollers with Bolt Hole
















4004 Black rubber caster with steel core, roller bearing

						
75×20		50	10.5	92.5	26	4004-75
85×25		60	10.5	102	34	4004-85
100×30		70	12.5	118.5	36	4004-100
125×35		100	12.5	148.5	36	4004-125
160×40		145	12.5	188	48	4004-160
200×50		185	12.5	229	48	4004-200














4005 Black rubber caster with steel core, roller bearing

							
75×20		50	10.5	92.5	32	90	4005-75
100×30		70	12.5	118.5	38	118	4005-100
125×35		100	12.5	148.5	36	120	4005-125
160×40		145	12.5	188	50	161	4005-160
200×50		185	12.5	229	52	161	4005-200














4024 Grey rubber caster with steel core, roller bearing

						
75×20		50	10.5	92.5	26	4024-75
85×25		60	10.5	102	34	4024-85
100×30		70	12.5	118.5	36	4024-100
125×35		100	12.5	148.5	36	4024-125
160×40		145	12.5	188	48	4024-160
200×50		185	12.5	229	48	4024-200















4025 Grey rubber caster with steel core, roller bearing

							
75 × 20		50	10.5	92.5	32	90	4025-75
100 × 30		70	12.5	118.5	38	118	4025-100
125×35		100	12.5	148.5	36	120	4025-125
160 × 40		145	12.5	188	50	161	4025-160
200 × 50		185	12.5	229	52	161	4025-200

4034 Rubber caster with PP core, roller bearing or plain bearing

							
						(Roller bearing)	(Plain bearing)
75×25		60	10.5	92.5	26	4034-75	
100×30		80	12.5	118.5	36	4034-100	4034-100-1
125×37		100	12.5	148.5	38	4034-125	4034-125-1
160×40		150	12.5	188	48	4034-160	
200×50		180	12.5	229	48	4034-200	

4035 Rubber caster with PP core, roller bearing or plain bearing

								
							(Roller bearing)	(Plain bearing)
75×25		60	10.5	92.5	32	90	4035-75	
100×30		80	12.5	118.5	38	118	4035-100	4035-100-1
125×37		100	12.5	148.5	36	120	4035-125	4035-125-1
160×40		150	12.5	188	50	161	4035-160	
200×50		180	12.5	229	52	161	4035-200	

4044 Grey rubber caster with PP core, roller bearing or plain bearing

							 (Roller bearing)	 (Plain bearing)
75×25			60	10.5	92.5	26	4044-75	
100×30			80	12.5	118.5	36	4044-100	4044-100-1
125×37			100	12.5	148.5	38	4044-125	4044-125-1
160×40			150	12.5	188	48	4044-160	
200×50			180	12.5	229	48	4044-200	














4045 Grey rubber caster with PP core, roller bearing or plain bearing

							 (Roller bearing)	 (Plain bearing)
75×25			60	10.5	92.5	32	90	4045-75
100×30			80	12.5	118.5	38	118	4045-100 4045-100-1
125×37			100	12.5	148.5	36	120	4045-125 4045-125-1
160×40			150	12.5	188	50	161	4045-160
200×50			180	12.5	229	52	161	4045-200




















4049 Elastic rubber caster with nylon core, plain bearing or roller bearing

							 (Roller bearing)	 (Plain bearing)
80×32			80	12.5	99.5	34		4049-80
100×32			100	12.5	118	36	4049-100	4049-100-1
125×36			150	12.5	148.5	38	4049-125	
160×50			200	12.5	188	48	4049-160	
200×50			280	12.5	229	48	4049-200	


















4050 Elastic rubber caster with nylon core, plain bearing or roller bearing

							 (Roller bearing)	 (Plain bearing)
100×32			100	12.5	118	38	118	4050-100 4050-100-1
125×36			150	12.5	148.5	36	120	4050-125
160×50			200	12.5	188	50	161	4050-160
200×50			280	12.5	229	52	161	4050-200

4064 Nylon caster, roller bearing or plain bearing

							 (Roller bearing)	 (Plain bearing)
75X32			80	10.5	92.5	26	4064-75	4064-75-1
100X32			150	12.5	118.5	36	4064-100	4064-100-1
125X38			180	12.5	148.5	38	4064-125	4064-125-1
152X40			250	12.5	184	48	4064-152	4064-152-1
200X48			300	12.5	229	48	4064-200	4064-200-1












4065 Nylon caster, roller bearing or plain bearing

								 (Roller bearing)	 (Plain bearing)
75X32			80	10.5	92.5	32	90	4065-75	4065-75-1
100X32			150	12.5	118.5	38	118	4065-100	4065-100-1
125X38			180	12.5	148.5	36	120	4065-125	4065-125-1
152X40			250	12.5	184	50	161	4065-152	4065-152-1
200X48			300	12.5	229	52	161	4065-200	4065-200-1

4094 PU caster with PP core, ball bearing

						
77X32		100	12.5	109	43	4094-77
101X32		150	12.5	133	38	4094-101
126X32		200	12.5	159.5	38	4094-126

4095 PU caster with PP core, ball bearing

							
77X32		100	12.5	109	43	108.5	4095-77
101X32		150	12.5	133	38	108.5	4095-101
126X32		200	12.5	159.5	37	108	4095-126











4204 TPR caster with PP core, ball bearing

						
77×32		80	12.5	109	43	4204-77
101×32		100	12.5	133	38	4204-101
126×32		120	12.5	159.5	38	4204-126












4205 TPR caster with PP core, ball bearing

							
77×32		80	12.5	109	43	108.5	4205-77
101×32		100	12.5	133	38	108.5	4205-101
126×32		120	12.5	159.5	37	108	4205-126

E-A05 PU caster with PP core, ball bearing, zinc plated or chrome plated

						
77X32		100	43	109	12.5	E-A05-77
101X32		150	38	133	12.5	E-A05-101
126X32		180	38	159.5	12.5	E-A05-126

E-A06 PU caster with PP core, ball bearing, zinc plated or chrome plated

							
77X32		100	43	109	12.5	108.5	E-A06-77
101X32		150	38	133	12.5	108.5	E-A06-101
126X32		180	37	159.5	12.5	108	E-A06-126

Алматы (7273)495-231
 Ангарск (3955)60-70-56
 Архангельск (8182)63-90-72
 Астрахань (8512)99-46-04
 Барнаул (3852)73-04-60
 Белгород (4722)40-23-64
 Благовещенск (4162)22-76-07
 Брянск (4832)59-03-52
 Владивосток (423)249-28-31
 Владикавказ (8672)26-90-48
 Владимир (4922)49-43-18
 Волгоград (844)278-03-48
 Вологда (8172)26-41-59
 Воронеж (473)204-51-73
 Екатеринбург (343)384-55-89

Иваново (4932)77-34-06
 Ижевск (3412)26-03-58
 Иркутск (395)279-98-46
 Казань (843)206-01-48
 Калининград (4012)72-03-81
 Калуга (4842)92-23-67
 Кемерово (3842)65-04-62
 Киров (8332)68-02-04
 Коломна (4966)23-41-49
 Кострома (4942)77-07-48
 Краснодар (861)203-40-90
 Красноярск (391)204-63-61
 Курск (4712)77-13-04
 Курган (3522)50-90-47
 Липецк (4742)52-20-81

Магнитогорск (3519)55-03-13
 Москва (495)268-04-70
 Мурманск (8152)59-64-93
 Набережные Челны (8552)20-53-41
 Нижний Новгород (831)429-08-12
 Новокузнецк (3843)20-46-81
 Ноябрьск (3496)41-32-12
 Новосибирск (383)227-66-73
 Омск (3812)21-46-40
 Орел (4862)44-53-42
 Оренбург (3532)37-68-04
 Пенза (8412)22-31-16
 Петрозаводск (8142)55-98-37
 Псков (8112)59-10-37
 Пермь (342)205-81-47

Ростов-на-Дону (863)308-18-15
 Рязань (4912)46-61-64
 Самара (846)206-03-16
 Санкт-Петербург (812)309-46-40
 Саратов (845)249-38-78
 Севастополь (8692)22-31-93
 Саранск (8342)22-96-24
 Симферополь (3652)67-13-56
 Смоленск (4812)29-41-54
 Сочи (862)225-72-31
 Ставрополь (8652)20-65-13
 Сургут (3462)77-98-35
 Сыктывкар (8212)25-95-17
 Тамбов (4752)50-40-97
 Тверь (4822)63-31-35

Тольятти (8482)63-91-07
 Томск (3822)98-41-53
 Тула (4872)33-79-87
 Тюмень (3452)66-21-18
 Ульяновск (8422)24-23-59
 Улан-Удэ (3012)59-97-51
 Уфа (347)229-48-12
 Хабаровск (4212)92-98-04
 Чебоксары (8352)28-53-07
 Челябинск (351)202-03-61
 Череповец (8202)49-02-64
 Чита (3022)38-34-83
 Якутск (4112)23-90-97
 Ярославль (4852)69-52-93

Россия +7(495)268-04-70

Казахстан +7(7172)727-132

Киргизия +996(312)96-26-47

<https://longway.nt-rt.ru/> || yaw@nt-rt.ru