

Алматы (7273)495-231
Ангарск (3955)60-70-56
Архангельск (8182)63-90-72
Астрахань (8512)99-46-04
Барнаул (3852)73-04-60
Белгород (4722)40-23-64
Благовещенск (4162)22-76-07
Брянск (4832)59-03-52
Владивосток (423)249-28-31
Владикавказ (8672)28-90-48
Владимир (4922)49-43-18
Волгоград (844)278-03-48
Вологда (8172)26-41-59
Воронеж (473)204-51-73
Екатеринбург (343)384-55-89

Иваново (4932)77-34-06
Ижевск (3412)26-03-58
Иркутск (395)279-98-46
Казань (843)206-01-48
Калининград (4012)72-03-81
Калуга (4842)92-23-67
Кемерово (3842)65-04-62
Киров (8332)68-02-04
Коломна (4966)23-41-49
Кострома (4942)77-07-48
Краснодар (861)203-40-90
Красноярск (391)204-63-61
Курск (4712)77-13-04
Курган (3522)50-90-47
Липецк (4742)52-20-81

Магнитогорск (3519)55-03-13
Москва (495)268-04-70
Мурманск (8152)59-64-93
Набережные Челны (8552)20-53-41
Нижегород (831)429-08-12
Новокузнецк (3843)20-46-81
Ноябрьск (3496)41-32-12
Новосибирск (383)227-86-73
Омск (3812)21-46-40
Орел (4862)44-53-42
Оренбург (3532)37-68-04
Пенза (8412)22-31-16
Петрозаводск (8142)55-98-37
Псков (8112)59-10-37
Пермь (342)205-81-47

Ростов-на-Дону (863)308-18-15
Рязань (4912)46-61-64
Самара (846)206-03-16
Санкт-Петербург (812)309-46-40
Саратов (845)249-38-78
Севастополь (8692)22-31-93
Саранск (8342)22-96-24
Симферополь (3652)67-13-56
Смоленск (4812)29-41-54
Сочи (862)225-72-31
Ставрополь (8652)20-65-13
Сургут (3462)77-98-35
Сыктывкар (8212)25-95-17
Тамбов (4752)50-40-97
Тверь (4822)63-31-35

Тольятти (8482)63-91-07
Томск (3822)98-41-53
Тула (4872)33-79-87
Тюмень (3452)66-21-18
Ульяновск (8422)24-23-59
Улан-Удэ (3012)59-97-51
Уфа (347)229-48-12
Хабаровск (4212)92-98-04
Чебоксары (8352)28-53-07
Челябинск (351)202-03-61
Череповец (8202)49-02-64
Чита (3022)38-34-83
Якутск (4112)23-90-97
Ярославль (4852)69-52-93

Россия +7(495)268-04-70

Казахстан +7(7172)727-132

Киргизия +996(312)96-26-47

<https://longway.nt-rt.ru/> || yaw@nt-rt.ru

Light and medium rollers with a rotary top plate



5101 TPR caster with PP core, ball bearing

		kg						
80×32		80	100X80 67X77	80X60 49X59	13X9 8.5X12	112.5	32	5101-80 5101-80-1
100×32		90	100X80 67X77	80X60 49X59	13X9 8.5X12	135	37	5101-100 5101-100-1
125×32		110	100X80 67X77	80X60 49X59	13X9 8.5X12	160	41	5101-125 5101-125-1
150×32		130	100X80 67X77	80X60 49X59	13X9 8.5X12	184.5	43	5101-150 5101-150-1

5101-PU PU caster with PP core, ball bearing

		kg						
100×32		120	100X80 67X77	80X60 49X59	13X9 8.5X12	135	37	5101-100-PU 5101-100-1-PU
125×32		150	100X80 67X77	80X60 49X59	13X9 8.5X12	160	41	5101-125-PU 5101-125-1-PU
150×32		130	100X80 67X77	80X60 49X59	13X9 8.5X12	184.5	43	5101-150-PU 5101-150-1-PU

5102 TPR caster with PP core, ball bearing

									
80×32		80	100X80 67X77	80X60 49X59	13X9 8.5X12	112.5	39	112	5102-80 5102-80-1
100×32		90	100X80 67X77	80X60 49X59	13X9 8.5X12	135	43	131	5102-100 5102-100-1
125×32		110	100X80 67X77	80X60 49X59	13X9 8.5X12	160	40	131	5102-125 5102-125-1
150×32		130	100X80 67X77	80X60 49X59	13X9 8.5X12	184.5	36	131	5102-150 5102-150-1

5102-PU PU caster with PP core, ball bearing

									
100×32		120	100X80 67X77	80X60 49X59	13X9 8.5X12	135	43	131	5102-100-PU 5102-100-1-PU
125×32		150	100X80 67X77	80X60 49X59	13X9 8.5X12	160	40	131	5102-125-PU 5102-125-1-PU
150×32		130	100X80 67X77	80X60 49X59	13X9 8.5X12	184.5	36	131	5102-150-PU 5102-150-1-PU

5102R TPR caster with PP core, ball bearing

									
80×32		80	100X80 67X77	80X60 49X59	13X9 8.5X12	112.5	39	112	5102R-80 5102R-80-1
100×32		90	100X80 67X77	80X60 49X59	13X9 8.5X12	135	43	131	5102R-100 5102R-100-1
125×32		110	100X80 67X77	80X60 49X59	13X9 8.5X12	160	40	131	5102R-125 5102R-125-1
150×32		130	100X80 67X77	80X60 49X59	13X9 8.5X12	184.5	36	131	5102R-150 5102R-150-1

5109 TPR caster with PP core, plain bearing

								
80×30		70	100X80 67X77	80X60 49X59	13X9 8.5X12	112.5	32	5109-80 5109-80-1
100×32		90	100X80 67X77	80X60 49X59	13X9 8.5X12	135	37	5109-100 5109-100-1
125×32		110	100X80 67X77	80X60 49X59	13X9 8.5X12	160	41	5109-125 5109-125-1
150×32		130	100X80 67X77	80X60 49X59	13X9 8.5X12	184.5	43	5109-150 5109-150-1

5110 TPR caster with PP core, plain bearing

									
80×30	=	70	100X80 67X77	80X60 49X59	13X9 8.5X12	112.5	39	112	5110-80 5110-80-1
100×32	=	90	100X80 67X77	80X60 49X59	13X9 8.5X12	135	43	131	5110-100 5110-100-1
125×32	=	110	100X80 67X77	80X60 49X59	13X9 8.5X12	160	40	131	5110-125 5110-125-1
150×32	=	130	100X80 67X77	80X60 49X59	13X9 8.5X12	184.5	36	131	5110-150 5110-150-1

5117 TPR caster with PP core, plain bearing

								
100×32	=	90	100X80 67X77	80X60 49X59	13X9 8.5X12	135	37	5117-100 5117-100-1
125×32	=	110	100X80 67X77	80X60 49X59	13X9 8.5X12	160	41	5117-125 5117-125-1
150×32	=	130	100X80 67X77	80X60 49X59	13X9 8.5X12	184.5	43	5117-150 5117-150-1

5118 TPR caster with PP core, plain bearing

									
100×32	=	90	100X80 67X77	80X60 49X59	13X9 8.5X12	135	43	131	5118-100 5118-100-1
125×32	=	110	100X80 67X77	80X60 49X59	13X9 8.5X12	160	40	131	5118-125 5118-125-1
150×32	=	130	100X80 67X77	80X60 49X59	13X9 8.5X12	184.5	36	131	5118-150 5118-150-1

Алматы (7273)495-231
Ангарск (3955)60-70-56
Архангельск (8182)63-90-72
Астрахань (8512)99-46-04
Барнаул (3852)73-04-60
Белгород (4722)40-23-64
Благовещенск (4162)22-76-07
Брянск (4832)59-03-52
Владивосток (423)249-28-31
Владикавказ (8672)28-90-48
Владимир (4922)49-43-18
Волгоград (844)278-03-48
Вологда (8172)26-41-59
Воронеж (473)204-51-73
Екатеринбург (343)384-55-89

Иваново (4932)77-34-06
Ижевск (3412)26-03-58
Иркутск (395)279-98-46
Казань (843)206-01-48
Калининград (4012)72-03-81
Калуга (4842)92-23-67
Кемерово (3842)65-04-62
Киров (8332)68-02-04
Коломна (4966)23-41-49
Кострома (4942)77-07-48
Краснодар (861)203-40-90
Красноярск (391)204-63-61
Курск (4712)77-13-04
Курган (3522)50-90-47
Липецк (4742)52-20-81

Магнитогорск (3519)55-03-13
Москва (495)268-04-70
Мурманск (8152)59-64-93
Набережные Челны (8552)20-53-41
Нижний Новгород (831)429-08-12
Новокузнецк (3843)20-46-81
Новосибирск (383)227-86-73
Омск (3812)21-46-40
Орел (4862)44-53-42
Оренбург (3532)37-68-04
Пенза (8412)22-31-16
Петрозаводск (8142)55-98-37
Пермь (342)205-81-47

Ростов-на-Дону (863)308-18-15
Рязань (4912)46-61-64
Самара (846)206-03-16
Санкт-Петербург (812)309-46-40
Саратов (845)249-38-78
Севастополь (8692)22-31-93
Саранск (8342)22-96-24
Симферополь (3652)67-13-56
Смоленск (4812)29-41-54
Сочи (862)225-72-31
Ставрополь (8652)20-65-13
Сургут (3462)77-98-35
Сыктывкар (8212)25-95-17
Тамбов (4752)50-40-97
Тверь (4822)63-31-35

Тольятти (8482)63-91-07
Томск (3822)98-41-53
Тула (4872)33-79-87
Тюмень (3452)66-21-18
Ульяновск (8422)24-23-59
Улан-Удэ (3012)59-97-51
Уфа (347)229-48-12
Хабаровск (4212)92-98-04
Чебоксары (8352)28-53-07
Челябинск (351)202-03-61
Череповец (8202)49-02-64
Чита (3022)38-34-83
Якутск (4112)23-90-97
Ярославль (4852)69-52-93

Россия +7(495)268-04-70

Казахстан +7(7172)727-132

Киргизия +996(312)96-26-47

<https://longway.nt-rt.ru/> || yaw@nt-rt.ru