

Алматы (7273)495-231
Ангарск (3955)60-70-56
Архангельск (8182)63-90-72
Астрахань (8512)99-46-04
Барнаул (3852)73-04-60
Белгород (4722)40-23-64
Благовещенск (4162)22-76-07
Брянск (4832)59-03-52
Владивосток (423)249-28-31
Владикавказ (8672)28-90-48
Владимир (4922)49-43-18
Волгоград (844)278-03-48
Вологда (8172)26-41-59
Воронеж (473)204-51-73
Екатеринбург (343)384-55-89

Иваново (4932)77-34-06
Ижевск (3412)26-03-58
Иркутск (395)279-98-46
Казань (843)206-01-48
Калининград (4012)72-03-81
Калуга (4842)92-23-67
Кемерово (3842)65-04-62
Киров (8332)68-02-04
Коломна (4966)23-41-49
Кострома (4942)77-07-48
Краснодар (861)203-40-90
Красноярск (391)204-63-61
Курск (4712)77-13-04
Курган (3522)50-90-47
Липецк (4742)52-20-81

Магнитогорск (3519)55-03-13
Москва (495)268-04-70
Мурманск (8152)59-64-93
Набережные Челны (8552)20-53-41
Нижний Новгород (831)429-08-12
Новокузнецк (3843)20-46-81
Ноябрьск (3496)41-32-12
Новосибирск (383)227-86-73
Омск (3812)21-46-40
Орел (4862)44-53-42
Оренбург (3532)37-68-04
Пенза (8412)22-31-16
Петрозаводск (8142)55-98-37
Псков (8112)59-10-37
Пермь (342)205-81-47

Ростов-на-Дону (863)308-18-15
Рязань (4912)46-61-64
Самара (846)206-03-16
Санкт-Петербург (812)309-46-40
Саратов (845)249-38-78
Севастополь (8692)22-31-93
Саранск (8342)22-96-24
Симферополь (3652)67-13-56
Смоленск (4812)29-41-54
Сочи (862)225-72-31
Ставрополь (8652)20-65-13
Сургут (3462)77-98-35
Сыктывкар (8212)25-95-17
Тамбов (4752)50-40-97
Тверь (4822)63-31-35

Тольятти (8482)63-91-07
Томск (3822)98-41-53
Тула (4872)33-79-87
Тюмень (3452)66-21-18
Ульяновск (8422)24-23-59
Улан-Удэ (3012)59-97-51
Уфа (347)229-48-12
Хабаровск (4212)92-98-04
Чебоксары (8352)28-53-07
Челябинск (351)202-03-61
Череповец (8202)49-02-64
Чита (3022)38-34-83
Якутск (4112)23-90-97
Ярославль (4852)69-52-93

Россия +7(495)268-04-70

Казахстан +7(7172)727-132

Киргизия +996(312)96-26-47

<https://longway.nt-rt.ru/> || yaw@nt-rt.ru

Industrial rollers with fixed top plate




A-M02 Elastic rubber caster with nylon core, roller bearing or plain bearing

									
80X34			80	100X84	80X60	16X9	110		A-M02-80
100X32			100	100X84	80X60	16X9	128	A-M02-100	A-M02-100-1
125X36			120	100X84	80X60	16X9	151	A-M02-125-1	
125X50			150	146X107	105X80	13X11	161	A-M02-125	
160X50			250	146X107	105X80	13X11	193	A-M02-160	
200X50			300	146X107	105X80	13X11	232.5	A-M02-200	

A-N02 Elastic rubber caster with nylon core, double ball bearings

							
125X50		180	146X107	105X80	13X11	161	A-N02-125
160X50		270	146X107	105X80	13X11	193	A-N02-160
200X50		350	146X107	105X80	13X11	232.5	A-N02-200

A-O02 PU caster mold on cast aluminium, double ball bearings

					
125X50		180	58	15	A-N01-125
160X50		270	58	20	A-N01-160
200X50		350	58	20	A-N01-200

A-P02 PU caster with PP core, ball bearing

							
100X32		150	100X84	80X60	16X9	128	A-P02-100
125X32		200	100X84	80X60	16X9	151	A-P02-125

A-Q02 Rubber caster mold on cast aluminium, double ball bearings

							
125X50		250	146X107	105X80	13X11	161	A-Q02-125
152X50		330	146X107	105X80	13X11	189	A-Q02-152
200X50		350	146X107	105X80	13X11	232.5	A-Q02-200
200X50		450	146X107	105X80	13X11	239	A-Q02-200-1
250X50		500	146X107	105X80	13X11	290	A-Q02-250

A-R02 Grey rubber caster mold on cast aluminium, double ball bearings

							
125X50		250	146X107	105X80	13X11	161	A-R02-125
152X50		330	146X107	105X80	13X11	189	A-R02-152
200X50		350	146X107	105X80	13X11	232.5	A-R02-200
200X50		450	146X107	105X80	13X11	237	A-R02-200-1
250X50		500	146X107	105X80	13X11	290	A-R02-250

A-S02 PU caster with PP core, double ball bearings or roller bearing

									
125X50			280	146X107	105X80	13X11	161	A-S02-125	A-S02-125-1
152X50			320	146X107	105X80	13X11	189	A-S02-152	A-S02-152-1
200X50			350	146X107	105X80	13X11	232.5	A-S02-200	A-S02-200-1

A-T02 PU caster mold on cast iron, roller bearing or double ball bearings

									
125X50			280	146X107	105X80	13X11	161	A-T02-125	A-T02-125B
152X50			350	146X107	105X80	13X11	189	A-T02-152	A-T02-152B
152X50			400	146X107	105X80	13X11	193	A-T02-152-1	A-T02-152-1B
200X50			450	146X107	105X80	13X11	232.5	A-T02-200	A-T02-200B
200X50			500	146X107	105X80	13X11	239	A-T02-200-1	A-T02-200-1B

A-V01 Aluminum alloy caster

							
97X35		120	100X84	80X60	16X9	126.5	A-V01-100

A-W02 Caster with PU mold on cast iron wheel, roller bearing

							
100X32		170	100X84	80X60	16X9	128	A-W02-100
125X35		200	100X84	80X60	16X9	151	A-W02-125
152X40		250	146X107	105X80	13X11	189	A-W02-152
200X40		350	146X107	105X80	13X11	232.5	A-W02-200

A-Z02 Black elastic rubber caster with steel core, double ball bearings

							
100X32		130	100X80	80X60	9X13	128	A-Z02-100
125X38		160	100X80	80X60	9X13	151	A-Z02-125

A-Z02-PU PU caster with steel core, double ball bearings

							
100X32		180	100X80	80X60	9X13	128	A-Z02-100-PU
125X38		230	100X80	80X60	9X13	151	A-Z02-125-PU

A-A02 Rubber caster with steel core, roller bearing or plain bearing

								
80X32		70	100X84	80X60	16X9	110	A-A02-80	A-A02-80-1
100X32		90	100X84	80X60	16X9	128	A-A02-100	A-A02-100-1
125X37		120	100X84	80X60	16X9	151	A-A02-125	A-A02-125-1
150X37		170	146X107	105X80	13X11	188	A-A02-150	A-A02-150-1
160X40		200	146X107	105X80	13X11	193	A-A02-160	A-A02-160-1
180X50		210	146X107	105X80	13X11	222.5	A-A02-180	A-A02-180-1
200X50		230	146X107	105X80	13X11	232.5	A-A02-200	A-A02-200-1
250X50		250	146X107	105X80	13X11	290	A-A02-250	

A-B02 Rubber caster with PP core, roller bearing or plain bearing

									
80X30		60	50	100X84	80X60	16X9	110	A-B02-80	A-B02-80-1
100X30		75	60	100X84	80X60	16X9	128	A-B02-100	A-B02-100-1
125X37		120	100	100X84	80X60	16X9	151	A-B02-125	A-B02-125-1
160X40		140	140	146X107	105X80	13X11	193	A-B02-160	A-B02-160-1
200X50		200	200	146X107	105X80	13X11	232.5	A-B02-200	A-B02-200-1
250X50		250		146X107	105X80	13X11	290	A-B02-250	

A-C02 Gray rubber caster with steel core, roller bearing or plain bearing

								 (Roller bearing)	 (Plain bearing)
80×32			70	100×84	80×60	16×9	110	A-C02-80	A-C02-80-1
100×32			90	100×84	80×60	16×9	128	A-C02-100	A-C02-100-1
125×37			120	100×84	80×60	16×9	151	A-C02-125	A-C02-125-1
150×37			170	146×107	105×80	13×11	188	A-C02-150	A-C02-150-1
160×40			200	146×107	105×80	13×11	193	A-C02-160	A-C02-160-1
180×50			210	146×107	105×80	13×11	222.5	A-C02-180	A-C02-180-1
200×50			230	146×107	105×80	13×11	232.5	A-C02-200	A-C02-200-1

A-D02 Gray rubber wheel with gray PP core, roller bearing or plain bearing

								 (Roller bearing)	 (Plain bearing)	
80X30		60		50	100X84	80X60	16X9	110	A-D02-80	A-D02-80-1
100X30		75		60	100X84	80X60	16X9	128	A-D02-100	A-D02-100-1
125X37		120		100	100X84	80X60	16X9	151	A-D02-125	A-D02-125-1
160X40		140		140	146X107	105X80	13X11	193	A-D02-160	A-D02-160-1
200X50		200		200	146X107	105X80	13X11	232.5	A-D02-200	A-D02-200-1

A-E02 TPR caster with PP core, roller bearing

							
80X32		80	100X84	80X60	16X9	110	A-E02-80
100X34		90	100X84	80X60	16X9	128	A-E02-100
125X37		120	100X84	80X60	16X9	151	A-E02-125
160X40		160	146X107	105X80	13X11	193	A-E02-160
200X50		210	146X107	105X80	13X11	232.5	A-E02-200

A-EU02 Elastic rubber caster with nylon core, ball bearing

							
100X36		200	100X84	80X60	16X9	128	A-EU02-100
125X36		230	100X84	80X60	16X9	151	A-EU02-125
150X40		280	146X107	105X80	13X11	188	A-EU02-150
200X50		350	146X107	105X80	13X11	232.5	A-EU02-200

A-F02 TPR caster with PP core, ball bearing

							
80X32		80	100X84	80X60	16X9	110	A-F02-80
100X32		110	100X84	80X60	16X9	128	A-F02-100
125X32		130	100X84	80X60	16X9	151	A-F02-125

A-G02 TPR caster with PP core, plain bearing

							
80X30		100	100X84	80X60	16X9	110	A-G02-80
100X30		120	100X84	80X60	16X9	128	A-G02-100
125X35		140	100X84	80X60	16X9	151	A-G02-125
160X40		160	146X107	105X80	13X11	193	A-G02-160
200X50		180	146X107	105X80	13X11	232.5	A-G02-200



A-H02 PU caster with nylon core, plain bearing

							
80X30		100	100X84	80X60	16X9	110	A-H02-80
100X30		120	100X84	80X60	16X9	128	A-H02-100
125X35		170	100X84	80X60	16X9	151	A-H02-125
125X40		220	146X107	105X80	13X11	161	A-H02-125-1
160X40		300	146X107	105X80	13X11	193	A-H02-160
200X50		350	146X107	105X80	13X11	232.5	A-H02-200


A-I02 PU caster with PP core, double ball bearings

							
125X40		250	146X107	105X80	13X11	161	A-I02-125
160X40		300	146X107	105X80	13X11	193	A-I02-160
200X50		350	146X107	105X80	13X11	232.5	A-I02-200
200X50		400	146X107	105X80	13X11	239	A-I02-200-1

A-J02 Nylon caster, plain bearing or roller bearing

								 (Roller bearing)	 (Plain bearing)
80X30			150	100X84	80X60	16X9	110	A-J02-80	A-J02-80-1
100X32			200	100X84	80X60	16X9	128	A-J02-100	A-J02-100-1
125X38			230	100X84	80X60	16X9	151	A-J02-125	A-J02-125-1
152X40			350	146X107	105X80	13X11	189	A-J02-152	A-J02-152-1
200X48			400	146X107	105X80	13X11	232.5	A-J02-200	A-J02-200-1

A-K02 PP caster, plain bearing or roller bearing

								 (Roller bearing)	 (Plain bearing)
80X30			150	100X84	80X60	16X9	110	A-K02-80	A-K02-80-1
100X32			200	100X84	80X60	16X9	128	A-K02-100	A-K02-100-1
125X38			230	100X84	80X60	16X9	151	A-K02-125	A-K02-125-1
152X40			350	146X107	105X80	13X11	189	A-K02-152	A-K02-152-1
200X48			400	146X107	105X80	13X11	232.5	A-K02-200	A-K02-200-1

A-L02 PP sandwich caster, roller bearing

							
100X32		110	100X84	80X60	16X9	128	A-L02-100
125X35		150	100X84	80X60	16X9	151	A-L02-125

Алматы (7273)495-231
Ангарск (3955)60-70-56
Архангельск (8182)63-90-72
Астрахань (8512)99-46-04
Барнаул (3852)73-04-60
Белгород (4722)40-23-64
Благовещенск (4162)22-76-07
Брянск (4832)59-03-52
Владивосток (423)249-28-31
Владикавказ (8672)28-90-48
Владимир (4922)49-43-18
Волгоград (844)278-03-48
Вологда (8172)26-41-59
Воронеж (473)204-51-73
Екатеринбург (343)384-55-89

Иваново (4932)77-34-06
Ижевск (3412)26-03-58
Иркутск (395)279-98-46
Казань (843)206-01-48
Калининград (4012)72-03-81
Калуга (4842)92-23-67
Кемерово (3842)65-04-62
Киров (8332)68-02-04
Коломна (4966)23-41-49
Кострома (4942)77-07-48
Краснодар (861)203-40-90
Красноярск (391)204-63-61
Курск (4712)77-13-04
Курган (3522)50-90-47
Липецк (4742)52-20-81

Магнитогорск (3519)55-03-13
Москва (495)268-04-70
Мурманск (8152)59-64-93
Набережные Челны (8552)20-53-41
Нижний Новгород (831)429-08-12
Новокузнецк (3843)20-46-81
Ноябрьск (3496)41-32-12
Новосибирск (383)227-86-73
Омск (3812)21-46-40
Орел (4862)44-53-42
Оренбург (3532)37-68-04
Пенза (8412)22-31-16
Петрозаводск (8142)55-98-37
Псков (8112)59-10-37
Пермь (342)205-81-47

Ростов-на-Дону (863)308-18-15
Рязань (4912)46-61-64
Самара (846)206-03-16
Санкт-Петербург (812)309-46-40
Саратов (845)249-38-78
Севастополь (8692)22-31-93
Саранск (8342)22-96-24
Симферополь (3652)67-13-56
Смоленск (4812)29-41-54
Сочи (862)225-72-31
Ставрополь (8652)20-65-13
Сургут (3462)77-98-35
Сыктывкар (8212)25-95-17
Тамбов (4752)50-40-97
Тверь (4822)63-31-35

Тольятти (8482)63-91-07
Томск (3822)98-41-53
Тула (4872)33-79-87
Тюмень (3452)66-21-18
Ульяновск (8422)24-23-59
Улан-Удэ (3012)59-97-51
Уфа (347)229-48-12
Хабаровск (4212)92-98-04
Чебоксары (8352)28-53-07
Челябинск (351)202-03-61
Череповец (8202)49-02-64
Чита (3022)38-34-83
Якутск (4112)23-90-97
Ярославль (4852)69-52-93

Россия +7(495)268-04-70

Казахстан +7(7172)727-132

Киргизия +996(312)96-26-47

<https://longway.nt-rt.ru/> || yaw@nt-rt.ru