

Алматы (7273)495-231
 Ангaрск (3955)60-70-56
 Архангельск (8182)63-90-72
 Астрахань (8512)99-46-04
 Барнаул (3852)73-04-60
 Белгород (4722)40-23-64
 Благовещенск (4162)22-76-07
 Брянск (4832)59-03-52
 Владивосток (423)249-28-31
 Владикавказ (8672)28-90-48
 Владимир (4922)49-43-18
 Волгоград (844)278-03-48
 Вологда (8172)26-41-59
 Воронеж (473)204-51-73
 Екатеринбург (343)384-55-89

Иваново (4932)77-34-06
 Ижевск (3412)26-03-58
 Иркутск (395)279-98-46
 Казань (843)206-01-48
 Калининград (4012)72-03-81
 Калуга (4842)92-23-67
 Кемерово (3842)65-04-62
 Киров (8332)68-02-04
 Коломна (4966)23-41-49
 Кострома (4942)77-07-48
 Краснодар (861)203-40-90
 Красноярск (391)204-63-61
 Курск (4712)77-13-04
 Кургaн (3522)50-90-47
 Липецк (4742)52-20-81

Магнитогорск (3519)55-03-13
 Москва (495)268-04-70
 Мурманск (8152)59-64-93
 Набережные Челны (8552)20-53-41
 Нижний Новгород (831)429-08-12
 Новокузнецк (3843)20-46-81
 Ноябрьск (3496)41-32-12
 Новосибирск (383)227-86-73
 Омск (3812)21-46-40
 Орел (4862)44-53-42
 Оренбург (3532)37-68-04
 Пенза (8412)22-31-16
 Петрозаводск (8142)55-98-37
 Псков (8112)59-10-37
 Пермь (342)205-81-47

Ростов-на-Дону (863)308-18-15
 Рязань (4912)46-61-64
 Самара (846)206-03-16
 Санкт-Петербург (812)309-46-40
 Саратов (845)249-38-78
 Севастополь (8692)22-31-93
 Саранск (8342)22-96-24
 Симферополь (3652)67-13-56
 Смоленск (4812)29-41-54
 Сочи (862)225-72-31
 Ставрополь (8652)20-65-13
 Сургут (3462)77-98-35
 Сыктывкар (8212)25-95-17
 Тамбов (4752)50-40-97
 Тверь (4822)63-31-35

Тольятти (8482)63-91-07
 Томск (3822)98-41-53
 Тула (4872)33-79-87
 Тюмень (3452)66-21-18
 Ульяновск (8422)24-23-59
 Улан-Удэ (3012)59-97-51
 Уфа (347)229-48-12
 Хабаровск (4212)92-98-04
 Чебоксары (8352)28-53-07
 Челябинск (351)202-03-61
 Череповец (8202)49-02-64
 Чита (3022)38-34-83
 Якутск (4112)23-90-97
 Ярославль (4852)69-52-93

Россия +7(495)268-04-70

Казахстан +7(7172)727-132

Киргизия +996(312)96-26-47

<https://longway.nt-rt.ru/> || yaw@nt-rt.ru

Industrial rollers with rotary top plate



A-M03 Elastic rubber caster with nylon core, roller bearing or plain bearing

80X34			80	100X80	80X60	13X9	110	35		A-M03-80
100X32			100	100X80	80X60	13X9	128	38	A-M03-100	A-M03-100-1
125X36			120	100X80	80X60	13X9	151	35	A-M03-125-1	
125X50			150	140X110	105X80	13X11	161	52	A-M03-125	
160X50			250	140X110	105X80	13X11	193	57	A-M03-160	
200X50			300	140X110	105X80	13X11	232.5	60	A-M03-200	

A-M04 Elastic rubber caster with nylon core, roller bearing or plain bearing

80X34			80	100X80	80X60	13X9	110	35	101		A-M04-80
100X32			100	100X80	80X60	13X9	128	37	101	A-M04-100	A-M04-100-1
125X36			120	100X80	80X60	13X9	151	35	108	A-M04-125-1	
125X50			150	140X110	105X80	13X11	161	52	148	A-M04-125	
160X50			250	140X110	105X80	13X11	193	57	145	A-M04-160	
200X50			300	140X110	105X80	13X11	232.5	60	163	A-M04-200	

A-N03 Elastic rubber caster with nylon core,double ball bearings

								
125X50		180	140X110	105X80	13X11	161	52	A-N03-125
160X50		270	140X110	105X80	13X11	193	57	A-N03-160
200X50		350	140X110	105X80	13X11	232.5	60	A-N03-200

A-N04 Elastic rubber caster with nylon core,double ball bearings

									
125X50		180	140X110	105X80	13X11	161	52	148	A-N04-125
160X50		270	140X110	105X80	13X11	193	57	145	A-N04-160
200X50		350	140X110	105X80	13X11	232.5	60	163	A-N04-200

A-O03 PU caster mold on cast aluminium, double ball bearings

								
125X50		250	140X110	105X80	13X11	161	52	A-O03-125
160X50		320	140X110	105X80	13X11	193	57	A-O03-160
160X50		380	140X110	105X80	13X11	197	59	A-O03-160-1
200X50		350	140X110	105X80	13X11	232.5	60	A-O03-200
200X50		500	140X110	105X80	13X11	239	61	A-O03-200-1

A-O09 PU caster mold on cast aluminium, double ball bearings

								
125X50		250	140X110	105X80	13X11	161	52	A-O09-125
160X50		320	140X110	105X80	13X11	193	57	A-O09-160
160X50		380	140X110	105X80	13X11	197	59	A-O09-160-1
200X50		350	140X110	105X80	13X11	232.5	60	A-O09-200
200X50		500	140X110	105X80	13X11	239	61	A-O09-200-1

A-P03 PU caster with PP core, ball bearing

								
100X32		150	100X80	80X60	13X9	128	38	A-P03-100
125X32		200	100X80	80X60	13X9	151	35	A-P03-125

A-P04 PU caster with PP core, ball bearing

									
100X32		150	100X80	80X60	13X9	128	37	104	A-P04-100
125X32		200	100X80	80X60	13X9	151	35	108	A-P04-125

A-Q03 Rubber caster mold on cast aluminium, double ball bearings

								
125X50		250	140X110	105X80	13X11	161	52	A-Q03-125
152X50		330	140X110	105X80	13X11	189	57	A-Q03-152
200X50		350	140X110	105X80	13X11	232.5	60	A-Q03-200
200X50		450	140X110	105X80	13X11	239	61	A-Q03-200-1
250X50		500	140X110	105X80	13X11	290	72	A-Q03-250

A-Q09 Rubber caster mold on cast aluminium, double ball bearings

								
125X50		250	140X110	105X80	13X11	161	52	A-Q09-125
152X50		330	140X110	105X80	13X11	189	57	A-Q09-152
200X50		350	140X110	105X80	13X11	232.5	60	A-Q09-200
200X50		450	140X110	105X80	13X11	239	61	A-Q09-200-1
250X50		500	140X110	105X80	13X11	290	72	A-Q09-250

A-R03 Grey rubber caster mold on cast aluminium, double ball bearings

								
125X50		250	140X110	105X80	13X11	161	52	A-R03-125
152X50		330	140X110	105X80	13X11	189	57	A-R03-152
200X50		350	140X110	105X80	13X11	232.5	60	A-R03-200
200X50		450	140X110	105X80	13X11	237	60	A-R03-200-1
250X50		500	140X110	105X80	13X11	290	72	A-R03-250

A-R09 Grey rubber caster mold on cast aluminium, double ball bearings

								
125X50		250	140X110	105X80	13X11	161	52	A-R09-125
152X50		330	140X110	105X80	13X11	189	57	A-R09-152
200X50		350	140X110	105X80	13X11	232.5	60	A-R09-200
200X50		450	140X110	105X80	13X11	237	60	A-R09-200-1
250X50		500	140X110	105X80	13X11	290	72	A-R09-250

A-S03 PU caster with PP core, double ball bearings or roller bearing

									(Roller bearing)	(Double ball bearings)
125X50			280	140X110	105X80	13X11	161	52	A-S03-125	A-S03-125-1
152X50			320	140X110	105X80	13X11	189	57	A-S03-152	A-S03-152-1
200X50			350	140X110	105X80	13X11	232.5	60	A-S03-200	A-S03-200-1

A-S04 PU caster with PP core, double ball bearings or roller bearing

										
125X50			280	140X110	105X80	13X11	161	52	148	A-S04-125 A-S04-125-1
152X50			320	140X110	105X80	13X11	189	57	145	A-S04-152 A-S04-152-1
200X50			350	140X110	105X80	13X11	232.5	60	163	A-S04-200 A-S04-200-1

A-T03 PU caster mold on cast iron, roller bearing or double ball bearings

											
125X50			280	140X110	105X80	13X11	161	52	A-T03-125	A-T03-125B	
152X50			350	140X110	105X80	13X11	189	57	A-T03-152	A-T03-152B	
152X50			400	140X110	105X80	13X11	193	59	A-T03-152-1	A-T03-152-1B	
200X50			450	140X110	105X80	13X11	232.5	60	A-T03-200	A-T03-200B	
200X50			500	140X110	105X80	13X11	239	61	A-T03-200-1	A-T03-200-1B	

A-T04 PU caster mold on cast iron, roller bearing or double ball bearings

											
125X50			280	140X110	105X80	13X11	161	52	148	A-T04-125	A-T04-125B
152X50			350	140X110	105X80	13X11	189	57	145	A-T04-152	A-T04-152B
152X50			400	140X110	105X80	13X11	193	59	145	A-T04-152-1	A-T04-152-1B
200X50			450	140X110	105X80	13X11	232.5	60	163	A-T04-200	A-T04-200B
200X50			500	140X110	105X80	13X11	239	61	163	A-T04-200-1	A-T04-200-1B

A-V02 Aluminum alloy caster

								
97X35		120	100X80	80X60	13X9	126.5	38	A-V02-100

A-W03 Caster with PU mold on cast iron wheel, roller bearing

								
100X32		170	100X80	80X60	13X9	128	38	A-W03-100
125X35		200	100X80	80X60	13X9	151	35	A-W03-125
152X40		250	140X110	105X80	13X11	189	57	A-W03-152
200X40		350	140X110	105X80	13X11	232.5	60	A-W03-200

A-W04 Caster with PU mold on cast iron wheel, roller bearing

									
100×32		170	100X80	80X60	13X9	128	37	104	A-W04-100
125×35		200	100X80	80X60	13X9	151	35	108	A-W04-125
152×40		250	140X110	105X80	13X11	189	57	145	A-W04-152
200×40		350	140X110	105X80	13X11	232.5	60	163	A-W04-200

A-Z03 Black elastic rubber caster with steel core, double ball bearings

								
100X32		130	100X80	80X60	13X9	128	38	A-Z03-100
125X38		160	100X80	80X60	13X9	151	35	A-Z03-125

A-Z03-PU PU caster with steel core, double ball bearings

								
100X32		180	100X80	80X60	13X9	128	38	A-Z03-100-PU
125X38		230	100X80	80X60	13X9	151	35	A-Z03-125-PU

A-Z04 Black elastic rubber caster with steel core, double ball bearings

									
100X32		130	100X80	80X60	13X9	128	37	104	A-Z04-100
125X38		160	100X80	80X60	13X9	151	35	108	A-Z04-125

A-Z04-PU PU caster with steel core, double ball bearings

									
100X32		180	100X80	80X60	13X9	128	37	104	A-Z04-100-PU
125X38		230	100X80	80X60	13X9	151	35	108	A-Z04-125-PU

I-A03 TPR caster with PP core, ball bearing

								
75X25		70	65X65	48X48	12X6.5	100	27	I-A03-75
100X32		110	76X76	57X57	15X8.5	126.5	33	I-A03-100
125X32		130	76X76	57X57	15X8.5	154.5	40	I-A03-125

J-B03 TPR caster with PP core, plain bearing

								
80X24		75	65X65	48X48	12X6.5	102.5	27	J-B03-80

J-C03 PU caster with PP core, plain bearing

								
80X24		75	65X65	48X48	12X6.5	102.5	27	J-C03-80

J-D03 Nylon caster, plain bearing, PP caster is available

								
75X22		85	65X65	48X48	12X6.5	100	27	J-D03-75

A-A03 Rubber caster with steel core, roller bearing or plain bearing

									 (Roller bearing)	 (Plain bearing)
80X32			70	100X80	80X60	13X9	110	35	A-A03-80	A-A03-80-1
100X32			90	100X80	80X60	13X9	128	38	A-A03-100	A-A03-100-1
125X37			120	100X80	80X60	13X9	151	35	A-A03-125	A-A03-125-1
150X37			170	140X110	105X80	13X11	188	57	A-A03-150	A-A03-150-1
160X40			200	140X110	105X80	13X11	193	57	A-A03-160	A-A03-160-1
180X50			210	140X110	105X80	13X11	222.5	60	A-A03-180	A-A03-180-1
200X50			230	140X110	105X80	13X11	232.5	60	A-A03-200	A-A03-200-1
250X50			250	140X110	105X80	13X11	290	72	A-A03-250	

A-A04 Rubber caster with steel core, roller bearing or plain bearing

											
80X32			70	100X80	80X60	13X9	110	35	101	A-A04-80	A-A04-80-1
100X32			90	100X80	80X60	13X9	128	37	104	A-A04-100	A-A04-100-1
125X37			120	100X80	80X60	13X9	151	35	108	A-A04-125	A-A04-125-1
150X37			170	140X110	105X80	13X11	188	57	145	A-A04-150	A-A04-150-1
160X40			200	140X110	105X80	13X11	193	57	145	A-A04-160	A-A04-160-1
200X50			230	140X110	105X80	13X11	232.5	60	163	A-A04-200	A-A04-200-1

A-B03 Rubber caster with PP core, roller bearing or plain bearing

											
80X30		60		50	100X80	80X60	13X9	110	35	A-B03-80	A-B03-80-1
100X30		75		60	100X80	80X60	13X9	128	38	A-B03-100	A-B03-100-1
125X37		120		100	100X80	80X60	13X9	151	35	A-B03-125	A-B03-125-1
160X40		140		140	140X110	105X80	13X11	193	57	A-B03-160	A-B03-160-1
200X50		200		200	140X110	105X80	13X11	232.5	60	A-B03-200	A-B03-200-1
250X50		250			140X110	105X80	13X11	290	72	A-B03-250	

A-B04 Rubber caster with PP core, roller bearing or plain bearing

											
80X30		60		50	100X80	80X60	13X9	110	35	101	A-B04-80
100X30		75		60	100X80	80X60	13X9	128	37	104	A-B04-100
125X37		120		100	100X80	80X60	13X9	151	35	108	A-B04-125
160X40		140		140	140X110	105X80	13X11	193	57	145	A-B04-160
200X50		200		200	140X110	105X80	13X11	232.5	60	163	A-B04-200

A-C03 Gray rubber caster with steel core, roller bearing or plain bearing

									 (Roller bearing)	 (Plain bearing)
80×32			70	100×80	80×60	13×9	110	35	A-C03-80	A-C03-80-1
100×32			90	100×80	80×60	13×9	128	38	A-C03-100	A-C03-100-1
125×37			120	100×80	80×60	13×9	151	35	A-C03-125	A-C03-125-1
150×37			170	140×110	105×80	13×11	188	57	A-C03-150	A-C03-150-1
160×40			200	140×110	105×80	13×11	193	57	A-C03-160	A-C03-160-1
180×50			210	140×110	105×80	13×11	222.5	60	A-C03-180	A-C03-180-1
200×50			230	140×110	105×80	13×11	232.5	60	A-C03-200	A-C03-200-1

A-C04 Gray rubber caster with steel core, roller bearing or plain bearing

									 (Roller bearing)	 (Plain bearing)	
80×32			70	100×80	80×60	13×9	110	35	101	A-C04-80	A-C04-80-1
100×32			90	100×80	80×60	13×9	128	37	104	A-C04-100	A-C04-100-1
125×37			120	100×80	80×60	13×9	151	35	108	A-C04-125	A-C04-125-1
150×37			170	140×110	105×80	13×11	188	57	145	A-C04-150	A-C04-150-1
160×40			200	140×110	105×80	13×11	193	57	145	A-C04-160	A-C04-160-1
200×50			230	140×110	105×80	13×11	232.5	60	163	A-C04-200	A-C04-200-1

A-D03 Gray rubber wheel with gray PP core, roller bearing or plain bearing

										 (Roller bearing)	 (Plain bearing)
80×30		60		50	100×80	80×60	13×9	110	35	A-D03-80	A-D03-80-1
100×30		75		60	100×80	80×60	13×9	128	38	A-D03-100	A-D03-100-1
125×37		120		100	100×80	80×60	13×9	151	35	A-D03-125	A-D03-125-1
160×40		140		140	140×110	105×80	13×11	193	57	A-D03-160	A-D03-160-1
200×50		200		200	140×110	105×80	13×11	232.5	60	A-D03-200	A-D03-200-1

A-D04 Gray rubber wheel with gray PP core, roller bearing or plain bearing

													
80X30		60		50	100X80	80X60	13X9	110	35	101	A-D04-80	A-D04-80-1	
100X30		75		60	100X80	80X60	13X9	128	37	104	A-D04-100	A-D04-100-1	
125X37		120		100	100X80	80X60	13X9	151	35	108	A-D04-125	A-D04-125-1	
160X40		140		140	140X110	105X80	13X11	193	57	145	A-D04-160	A-D04-160-1	
200X50		200		200	140X110	105X80	13X11	232.5	60	163	A-D04-200	A-D04-200-1	

A-E03 TPR caster with PP core, roller bearing

								
80X32		80	100X80	80X60	13X9	110	35	A-E03-80
100X34		90	100X80	80X60	13X9	128	38	A-E03-100
125X37		120	100X80	80X60	13X9	151	35	A-E03-125
160X40		160	140X110	105X80	13X11	193	57	A-E03-160
200X50		210	140X110	105X80	13X11	232.5	60	A-E03-200

A-E04 TPR caster with PP core, roller bearing

									
80X32		80	100X80	80X60	13X9	110	35	101	A-E04-80
100X34		90	100X80	80X60	13X9	128	37	104	A-E04-100
125X37		120	100X80	80X60	13X9	151	35	108	A-E04-125
160X40		160	140X110	105X80	13X11	193	57	145	A-E04-160
200X50		210	140X110	105X80	13X11	232.5	60	163	A-E04-200

A-EU03 Elastic rubber caster with nylon core, ball bearing

								
100X36		200	100X80	80X60	13X9	128	38	A-EU03-100
125X36		230	100X80	80X60	13X9	151	35	A-EU03-125
150X40		280	140X110	105X80	13X11	188	57	A-EU03-150
200X50		350	140X110	105X80	13X11	232.5	60	A-EU03-200

A-EU04 Elastic rubber caster with nylon core, ball bearing

									
100x36		200	100X80	80X60	13X9	128	37	104	A-EU04-100
125X36		230	100X80	80X60	13X9	151	35	108	A-EU04-125
150X40		280	140X110	105X80	13X11	188	57	145	A-EU04-150
200X50		350	140X110	105X80	13X11	232.5	60	163	A-EU04-200

A-F03 TPR caster with PP core, ball bearing

								
80X32		80	100X80	80X60	13X9	110	35	A-F03-80
100X32		110	100X80	80X60	13X9	128	38	A-F03-100
125X32		130	100X80	80X60	13X9	151	35	A-F03-125

A-F04 TPR caster with PP core, ball bearing

									
80X32		80	100X80	80X60	13X9	110	35	101	A-F04-80
100X32		110	100X80	80X60	13X9	128	37	104	A-F04-100
125X32		130	100X80	80X60	13X9	151	35	108	A-F04-125

A-G03 TPR caster with PP core, plain bearing

								
80X30		100	100X80	80X60	13X9	110	35	A-G03-80
100X30		120	100X80	80X60	13X9	128	38	A-G03-100
125X35		140	100X80	80X60	13X9	151	35	A-G03-125
160X40		160	140X110	105X80	13X11	193	57	A-G03-160
200X50		180	140X110	105X80	13X11	232.5	60	A-G03-200

A-G04 TPR caster with PP core, plain bearing

									
80X30		100	100X80	80X60	13X9	110	35	101	A-G04-80
100X30		120	100X80	80X60	13X9	128	37	104	A-G04-100
125X35		140	100X80	80X60	13X9	151	35	108	A-G04-125
160X40		160	140X110	105X80	13X11	193	57	145	A-G04-160
200X50		180	140X110	105X80	13X11	232.5	60	163	A-G04-200


A-H03 PU caster with nylon core, plain bearing

								
80X30		100	100X80	80X60	13X9	110	35	A-H03-80
100X30		120	100X80	80X60	13X9	128	38	A-H03-100
125X35		170	100X80	80X60	13X9	151	35	A-H03-125
125X40		220	140X110	105X80	13X11	161	52	A-H03-125-1
160X40		300	140X110	105X80	13X11	193	57	A-H03-160
200X50		350	140X110	105X80	13X11	232.5	60	A-H03-200

A-H04 PU caster with nylon core, plain bearing

									
80X30		100	100X80	80X60	13X9	110	35	101	A-H04-80
100X30		120	100X80	80X60	13X9	128	37	104	A-H04-100
125X35		170	100X80	80X60	13X9	151	35	108	A-H04-125-1
160X40		300	140X110	105X80	13X11	193	57	145	A-H04-160
200X50		350	140X110	105X80	13X11	232.5	60	163	A-H04-200

A-I03 PU caster with PP core, double ball bearings

								
125X40		250	140X110	105X80	13X11	161	52	A-I03-125
160X40		300	140X110	105X80	13X11	193	57	A-I03-160
200X50		350	140X110	105X80	13X11	232.5	60	A-I03-200
200X50		400	140X110	105X80	13X11	239	61	A-I03-200-1

A-I04 PU caster with PP core, double ball bearings

									
125X40		250	140X110	105X80	13X11	161	52	148	A-I04-125
160X40		300	140X110	105X80	13X11	193	57	145	A-I04-160
200X50		350	140X110	105X80	13X11	232.5	60	163	A-I04-200
200X50		400	140X110	105X80	13X11	239	61	163	A-I04-200-1

A-J03 Nylon caster, plain bearing or roller bearing

									 (Roller bearing)	 (Plain bearing)
80X30			150	100X80	80X60	13X9	110	35	A-J03-80	A-J03-80-1
100X32			200	100X80	80X60	13X9	128	38	A-J03-100	A-J03-100-1
125X38			230	100X80	80X60	13X9	151	35	A-J03-125	A-J03-125-1
152X40			350	140X110	105X80	13X11	189	57	A-J03-152	A-J03-152-1
200X48			400	140X110	105X80	13X11	232.5	60	A-J03-200	A-J03-200-1

A-J04 Nylon caster, plain bearing or roller bearing

										 (Roller bearing)	 (Plain bearing)
80X30			150	100X80	80X60	13X9	110	35	101	A-J04-80	A-J04-80-1
100X32			200	100X80	80X60	13X9	128	37	104	A-J04-100	A-J04-100-1
125X38			230	100X80	80X60	13X9	151	35	108	A-J04-125	A-J04-125-1
152X40			350	140X110	105X80	13X11	189	57	145	A-J04-152	A-J04-152-1
200X48			400	140X110	105X80	13X11	232.5	60	163	A-J04-200	A-J04-200-1

A-K03 PP caster, plain bearing or roller bearing

									 (Roller bearing)	 (Plain bearing)
80X30			150	100X80	80X60	13X9	110	35	A-K03-80	A-K03-80-1
100X32			200	100X80	80X60	13X9	128	38	A-K03-100	A-K03-100-1
125X38			230	100X80	80X60	13X9	151	35	A-K03-125	A-K03-125-1
152X40			350	140X110	105X80	13X11	189	57	A-K03-152	A-K03-152-1
200X48			400	140X110	105X80	13X11	232.5	60	A-K03-200	A-K03-200-1

A-K04 PP caster, plain bearing or roller bearing

											
80X30		150	100X80	80X60	13X9	110	35	101	A-K04-80	A-K04-80-1	
100X32		200	100X80	80X60	13X9	128	37	104	A-K04-100	A-K04-100-1	
125X38		230	100X80	80X60	13X9	151	35	108	A-K04-125	A-K04-125-1	
152X40		350	140X110	105X80	13X11	189	57	145	A-K04-152	A-K04-152-1	
200X48		400	140X110	105X80	13X11	232.5	60	163	A-K04-200	A-K04-200-1	

A-L03 PP sandwich caster, roller bearing

								
100X32		110	100X80	80X60	13X9	128	38	A-L03-100
125X35		150	100X80	80X60	13X9	151	35	A-L03-125

A-L04 PP sandwich caster, roller bearing

									
100X32		110	100X80	80X60	13X9	128	37	104	A-L04-100
125X35		150	100X80	80X60	13X9	151	35	108	A-L04-125

Алматы (7273)495-231
 Ангарск (3955)60-70-56
 Архангельск (8182)63-90-72
 Астрахань (8512)99-46-04
 Барнаул (3852)73-04-60
 Белгород (4722)40-23-64
 Благовещенск (4162)22-76-07
 Брянск (4832)59-03-52
 Владивосток (423)249-28-31
 Владикавказ (8672)26-90-48
 Владимир (4922)49-43-18
 Волгоград (844)278-03-48
 Вологда (8172)26-41-59
 Воронеж (473)204-51-73
 Екатеринбург (343)384-55-89

Иваново (4932)77-34-06
 Ижевск (3412)26-03-58
 Иркутск (395)279-98-46
 Казань (843)206-01-48
 Калининград (4012)72-03-81
 Калуга (4842)92-23-67
 Кемерово (3842)65-04-62
 Киров (8332)68-02-04
 Коломна (4966)23-41-49
 Кострома (4942)77-07-48
 Краснодар (861)203-40-90
 Красноярск (391)204-63-61
 Курск (4712)77-13-04
 Курган (352)50-90-47
 Липецк (4742)52-20-81

Магнитогорск (3519)55-03-13
 Москва (495)268-04-70
 Мурманск (8152)59-64-93
 Набережные Челны (8552)20-53-41
 Нижний Новгород (831)429-08-12
 Новокузнецк (3843)20-46-81
 Ноябрьск (3496)41-32-12
 Новосибирск (383)227-86-73
 Омск (3812)21-46-40
 Орел (4862)44-53-42
 Оренбург (3532)37-68-04
 Пенза (8412)22-31-16
 Петрозаводск (8142)55-98-37
 Псков (8112)59-10-37
 Пермь (342)205-81-47

Ростов-на-Дону (863)308-18-15
 Рязань (4912)46-61-64
 Самара (846)206-03-16
 Санкт-Петербург (812)309-46-40
 Саратов (845)249-38-78
 Севастополь (8692)22-31-93
 Саранск (8342)22-96-24
 Симферополь (3652)67-13-56
 Смоленск (4812)29-41-54
 Сочи (862)225-72-31
 Ставрополь (8652)20-65-13
 Сургут (3462)77-98-35
 Сыктывкар (8212)25-95-17
 Тамбов (4752)50-40-97
 Тверь (4822)63-31-35

Тольятти (8482)63-91-07
 Томск (3822)98-41-53
 Тула (4872)33-79-87
 Тюмень (3452)66-21-18
 Ульяновск (8422)24-23-59
 Улан-Удэ (3012)59-97-51
 Уфа (347)229-48-12
 Хабаровск (4212)92-98-04
 Чебоксары (8352)28-53-07
 Челябинск (351)202-03-61
 Череповец (8202)49-02-64
 Чита (3022)38-34-83
 Якутск (4112)23-90-97
 Ярославль (4852)69-52-93

Россия +7(495)268-04-70

Казахстан +7(7172)727-132

Киргизия +996(312)96-26-47

<https://longway.nt-rt.ru/> || yaw@nt-rt.ru